

1 Annex C – EUT pictures internal


1.1 List of Pictures

Picture 1: Opened EUT – top side.....	2
Picture 2: Opened EUT – bottom side.....	2
Picture 3: Main PCB – top side	3
Picture 4: Touch PCB – top side	3
Picture 5: Touch PCB, – bottom side	4
Picture 6 Main PCB and touch PCB decoupled	4
Picture 7: Opened EUT - top side	5
Picture 8: Opened EUT – bottom side.....	5
Picture 9: Main PCB – top side	6
Picture 10: Touch PCB – top side	6
Picture 11: Touch PCB – bottom side	7
Picture 12: Main PCB and touch PCB decoupled	7


EUT with integrated antenna



Picture 1: Opened EUT – top side




Picture 2: Opened EUT – bottom side




Picture 3: Main PCB – top side



Picture 4: Touch PCB – top side




Picture 5: Touch PCB, – bottom side




Picture 6 Main PCB and touch PCB decoupled


EUT with temporary antenna port



Picture 7: Opened EUT - top side




Picture 8: Opened EUT – bottom side




Picture 9: Main PCB – top side



Picture 10: Touch PCB – top side



Picture 11: Touch PCB – bottom side



Picture 12: Main PCB and touch PCB decoupled