



1. LCD	2. 【OK】 key	3. 【C】 key
4. 【IP】key	5. 【Menu】key	6. 【Redial】 key
7. Hand free key	8. Numerical key	9. Handset
10. Power jack	11. Data port	12. Power switch
13. Antenna	14. Handset cable jack	15. GSM tray

Introduction of the Function Key

1、【Menu】 key:

When pressing this key, it will prompt you to input the user password, if the password is correct, it will show following menu in turn by pressing this key continually:

(1) Call Records	(2) Time & date settings	(3) Password Changing
(4) Alarm settings	(5) Call Amount	(6) Language
(7) Alarm mode		

If you want to enter submenu, please press corresponding numerical key

RF Exposure Warning: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device's provided antenna must be installed in accordance with provided instructions; and it must be operated with minimum 20 cm spacing between the antennas and all person's body (excluding extremities of hands, wrist and feet) during wireless mode of operation. Further, this transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.