## **Base Station-EA1000-Fast User Manual**



INDICATE LED	(1) Connection status light flashes slowly: connect base station to computer successfully.
	(2) Connection status light flashes fast: connect base station and application software successfully.
	(3) Working status light flashes: base station has received keypad data successfully (The
	light flashes quickly in non-response state, representing another base station is using
	the same channel identity).
BASE STATION	Connect the base station with PC USB port , the Status LED will flash every half
CONNECTION	second if connection is successful.
	The Status LED will flash quickly after the software and base station communicate
	normally.
	Initial installation, PC will automatically remind that have found new device and
	install the drive automatically.
RADIO	After logging in application software, choose the new channel in the "channel" of
CHANNEL SET	"base station set", then click "set".
	When using the multiple base station solution, the frequency channel of each base
	station should be different, and it's better not to set the neighboring channel
	Only when frequency channel is interfered or communication is not good, then you
	need to consider changing and resetting the channel, otherwise you do not need to change
	it.
BASE STATION	After connetion is ok, then start keypads testing.
TEST	

<u>www.sunvote.com.cn</u> +86-731-85123999 **1/2** 

## **FCC Warning**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

## RF exposure statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

<u>www.sunvote.com.cn</u> +86-731-85123999 **2/2**