

User Manual

S.M Development Co., Ltd.

MySlave-100-Kit

Product Details:

The MySlave-100-Kit is a digitalized radio trigger system designed for photographic studios and on-location work. It is composed of two units: a radio Transmitter and a digital Receiver, both easily installed on any type of light. The MySlave-100-Kit can be used with a variety of studio flashes, strobes (AC & DC), and monolights (monobloc). The MySlave-100-Kit will eliminate flash slave interference among strobe lights in your studio.

Features

1. Ten (10) optional channels
2. A triggering speed of up to 1/180 second
3. Operational range : 50~60 meters
4. Built-in Hotshoe on the Receiver
5. A trigger battery with a lifetime of up to one year, or over 20,000 triggers
6. Low Voltage Trigger, No Damage to Camera
7. Test button on Trigger
8. LED signals for each trigger/reception
9. Receiver adapters for the synch cord outlets of different strobes
10. Various sync sockets on the Receiver- PC Terminal, 2.5mm sub-mini phone plug, Built-in Hotshoe

User Guide

1. Insert 23A 12V battery into the Transmitter.
2. Affix the TRANSMITTER to the hot shoe of your camera or use the supplied pc cord by inserting the mini phone (male end) plug in the hole on the side of the TRANSMITTER and then the PC end of the cable into your camera's PC terminal.
3. Insert the 3 pcs of "AAA" batteries into the RECEIVER. (Observe the polarity of the batteries as indicated)
4. Connect the RECEIVER to your strobe properly in one of two ways;
 - a) Receiver provides a PC to 3.5mm phone jack plug cable for connecting the output to your flash unit's sync input.OR
 - b) Mount your portable flash unit into the built-in Hotshoe on the RECEIVER directly.
5. Using a mini flat ended screw driver, dial in the same channel number (1-10) on the channel selector both the TRANSMITTER and RECEIVER.
6. There is a test button on the top of the TRANSMITTER that can be used to verify that the system is operational. The Status button flashes blue to indicate synchronization.

MySlave 100 Radio Trigger & Receiver Kit Contents:

- 1 - Radio Trigger(Battery Installed: 23A)
- 1 - Radio Receiver(Battery Required: three "AAA" 1.5V)
- 1 - Synch Cord Adapter 3.5-6.3mm
- 1 - Synch Cord (for camera)
- 1 - Synch Cord (for strobe light)
- 1 – Plastic Hotshoe and grip for Receiver
- 1 – Pole mounting plastic strap
- 1 - Instructional Manual

Warranty

S.M Development guarantees all our products for one year from date of purchase. We will repair or replace any our products that become defective during the period. Defective units should be sent back to us with a message describing the defects.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications (including the antennas) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.