



<p>English</p> <hr/> <p>Features:</p> <ol style="list-style-type: none"> Left and right mouse button Scroll wheel Press the scroll wheel in order to use the middle key function (this will vary depending on the application) Plug the ClickCarMouse into a USB port on the computer, keyboard or screen. Thanks to the convenient Plug&Play function, the ClickCarMouse is always ready to use without having to install any additional software  <p>CLICK CAR MOUSE®</p>	<p>Deutsch</p> <hr/> <p>Funktionen:</p> <ol style="list-style-type: none"> Linke und rechte Maustaste Intermed Drücken Sie das Tastenrad, um die Funktion der mittleren Taste auszuüben (je nach Anwendung unterschiedlich) Stecken Sie die ClickCarMouse in einen USB-Anschluss des Computers, der Tastatur oder des Monitors. Durch die funktionale Plug&Play Funktion ist die ClickCarMouse immer einsatzbereit ohne weitere Installation von Software. 	<p>Français</p> <hr/> <p>Fonctions:</p> <ol style="list-style-type: none"> Boutons droit et gauche de la souris Rouelette de défilement Cliquer sur la roulette pour activer la fonction du bouton du milieu (cette fonction varie suivant l'application logicielle) Connecter le ClickCarMouse dans un port USB de l'ordinateur, du clavier ou de l'écran. Grâce à la fonction Plug&Play, la souris ClickCarMouse est toujours prête à l'emploi, il n'y a pas de logiciel à installer <p>Español</p> <hr/> <p>Funciones:</p> <ol style="list-style-type: none"> Botón izquierdo y derecho del ratón Puede del ratón Pulse en la rueda del ratón para ejecutar la función de la tecla central (varia según la aplicación) Conecte la ClickCarMouse a un puerto USB del ordenador, el teclado o el monitor. Gracias a la cómoda función Plug&Play el ClickCarMouse está siempre listo para usarse sin necesidad de instalar software <p>CLICK CAR MOUSE®</p>
<p>© 2010 Fross Trading GmbH in Switzerland has all rights reserved. The verbal elements ClickCarMouse® e control by Fross Trading GmbH in Switzerland and is registered. All other trademarks are the property of their respective owners. ClickCarMouse appears no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice. C009B</p> <p>www.clickcarmouse.com</p>	<p>Italiano</p> <hr/> <p>Caratteristiche:</p> <ol style="list-style-type: none"> Tasto destro e sinistro del mouse Rondella del mouse Premere la rotellina del mouse per attivare la funzione del tasto medio del mouse (può divergere a seconda dell'applicazione) Collegare la ClickCarMouse a un collegamento USB del computer, della tastiera e dello schermo. Grazie alla pratica funzione Plug&Play, il ClickCarMouse è sempre pronto per l'uso senza dover installare un ulteriore software 	

FCC warning statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.