

Annex C Internal Photographs




EUT open 1

Annex C Internal Photographs




EUT open 2

Annex C Internal Photographs



EUT disassembled

Annex C Internal Photographs




Main PCB – top view

Annex C Internal Photographs




Connector PCB– top view

Annex C Internal Photographs




Connector PCB– bottom view

Annex C Internal Photographs




Connector PCB– bottom view

Annex C Internal Photographs




Connector + USB PCB– top view

Annex C Internal Photographs



Connector + USB PCB – bottom view

Annex C Internal Photographs




B620WS / B650WS, USB PCB, top view

Annex C Internal Photographs




B620WS / B650WS, USB PCB, bottom view

Annex C Internal Photographs



Wi-Fi Board – top view

Annex C Internal Photographs



Wi-Fi Board – bottom view