

Features:

1. Convenient control for accent lights.
2. No fumbling for a switch, just touch the pad!
3. Get 3 level touch dimmer from your accent lighting systems
4. Touch pad may be places in any convenient location.
5. Example: attach under cabinet, set on counter, on shelf .etc.
6. Touch pad fits any decor.
7. Installs in seconds, No wiring required!


Specifications:

120V 60Hz

Low Voltage Halogen(12V)

Or incandescent(120V) Lights Only

For indoor Use Only



INSTALLATION:

Do not use this dimmer with another dimmer in the same circuit

1. Plug accent light into the dimmer module.
2. Plug dimmer wire into wall outlet .
3. Place the pad in any convenient location.
4. Just touch the pad to advance the light to the next position.
1 st touch is 10% light, 2 nd is 50%, the 3 rd touch is 100%
Light and the 4 th touch is off .

FCC NOTE:

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to the equipment. Such modification could void the user's authority to operate the equipment.

This product may cause interference to radio equipment and should not be installed near maritime safety communications equipment or other critical navigation or communication equipment operating between 0.45-30MHz.