

SHARP®

Quick Start Guide
SH837Wi

Introduction

Thank you for choosing Sharp SH837Wi phone. The first time you use this phone, it is recommended that you first read the User Guide to understand the basic operation of the phone.

For more detailed information, see the user manual. Please visit the following URL to download the user manual:

www.sharp.cn/download/mobile/SH837Wi



Note

The phone can be used within the territory of the People's Republic of China. This phone may not work properly in some countries and regions outside China.

Content


Your Phone	2
Installing SIM Card, Memory Card, and Battery	3
Charging the Battery	4
First Start Up	4
Home Screen	4
Making Your First Call	5
People	6
Sending a Text Message	7
Setting up Wi-Fi	7
Setting up Email Account	8
Sending and Receiving Emails	8
Using Browser	9
Using Bluetooth	10
Taking Photos and Videos	10
Viewing Photos and Videos	12
Changing Basic Phone Settings	13

Your Phone



Installing SIM Card


1. Open the bottom antenna cap.
2. Insert the SIM card into the SIM tray as shown.
3. Close the bottom antenna cap.



Charging the Battery

The battery is only partially charged.

1. Connect the USB cable to the USB port of the device.
2. Connect the other end of the USB cable to the AC adapter.
3. Plug the AC adapter to a wall outlet to start charging.



Warning

- Please use indoors and in dry places.
- Overheat protection mechanism is activated, the device will temporarily stop charging:
When the system temperature reaches the maximum operating temperature, the device will automatically activate the overheat protection mechanism and temporarily stops battery charging. When the system temperature drops, the system will automatically restart the battery

charging.


First Start Up

After installing the SIM card and charging the battery, the device is ready to be turned on.

Home Screen

From the Home screen, you can quickly access common features and view notifications of missed calls, received messages, check battery and connection status.

Tap **APPS** tab to access all the applications and settings of the device.



Making Your First Call


From the Home screen, tap **Phone**.

To make a call

1. Tap the phone number on the keypad.
2. Tap  to erase a wrong number. Tap and hold  to erase the entire number.


NOTE: To call a contact, tap the contact from the list.

3. Tap .
4. To end the call, tap .



To answer a call

To answer a call, tap  and drag it to the right ().




NOTE: When you tap , it automatically changes to .

People


Adding contacts

1. From the Home screen, tap **People**.
2. Tap  to add a contact.
3. Select one of the location to store the contact to (USIM-only or Phone-only).
4. Enter the contact information such as name, phone number, email address, etc.
5. Tap  **DONE** to save the contact.




Importing contacts

1. From the Home screen, tap **People**.
2. Tap  > **Import/export**.
3. Select the contacts location that you want to copy from and tap **Next**.
4. Select the contacts location that you want to copy to and tap **Next**.
5. Select the contacts to copy and tap .



Sending a Text Message

1. From the Home screen, tap **Messaging**.
2. Tap .
3. In the **To** field, enter the recipient's phone number.
4. Compose your message.
5. Tap  to send your message.



Setting up Wi-Fi


1. From the Home screen, tap **Settings**.
2. In **WIRELESS & NETWORKS**, tap **Wi-Fi** and set it to **ON**.
3. Available networks are listed. Tap a network to connect to or tap **ADD NETWORK** to manually add a connection.

NOTE: Connecting to a secured network will prompt for a password. Enter the password, then tap **Connect**.



Setting up Email Account


1. From the Home screen, tap **Email**.
2. Enter your **Email address** and **Password** and tap **Next**.
3. Set the **Inbox checking frequency** settings and tap **Next**.
4. Enter **Name** and **Account display name**.
5. Tap **Next**. Once the account setup is complete, the device will automatically retrieve your emails.



Sending and Receiving Emails

Composing and sending emails


1. From the Home screen, tap **Email**, then tap an e-mail account.
2. Tap .
3. In the **To** field, enter the recipient's email address.
4. Enter the **Subject**.
5. Compose your email.
 - Tap  > **Attach file** and select the item to attach.



6. Tap ➤.

Receiving emails

Emails are automatically received in the Inbox folder when the device connects to a network. To manually retrieve new emails, tap .



Using Browser

To open a web page

1. From the Home screen, tap **Browser**.
2. Tap the address bar.
3. Type the URL then tap **Go**.
4. Tap  to access more functions.



Using Bluetooth

1. From the Home screen, tap **Settings**.
2. In **WIRELESS & NETWORKS**, tap **Bluetooth** and set it to **ON**.
3. Available devices are listed. To search for a new device, tap **SEARCH FOR DEVICES**.
4. Tap a detected device.
5. To start pairing, enter the **PIN** then tap **OK**.

NOTE:

- The PIN of the device must be the same PIN on the other bluetooth device.
- On some devices, tap **Pair** to start pairing.

6. The paired bluetooth device name is displayed.

Taking Photos and Videos

This device is equipped with rear and front cameras to take photos and videos.


1. From the Home screen, tap **Camera**.

NOTE: To switch between front and rear cameras, tap .

2. Aim the device at the subject.


Drag  to the right/left to zoom in/out on the subject.

3. Tap  to take the shot.




To record video

1. From the Home screen, tap **Camera**.
2. Tap  and select  to enter video mode.
- NOTE:** To switch between front and rear cameras, tap .
3. Aim the device at the subject.
4. Tap  to start recording.
Tap and hold  to pause the recording. Tap  again to resume.
5. Tap  to stop recording.



To take a panorama shot

1. From the Home screen, tap **Camera**.
2. Tap  and select  to enter panorama mode.
3. Aim the device at the subject.
4. Tap  to take the shot.
5. Move the device in one direction and overlay the focus area with the blue frame.
6. When the shooting guide reaches the end of the shooting point, the shooting ends. You can also manually stop recording by tapping .




Viewing Photos and Videos

1. From the Home screen, tap **Gallery**.
2. Tap a folder to view the recorded files in thumbnails.
3. Tap an image or a video to view in full screen.

4. Swipe your finger to the left/right to view the previous/next file.

- To share the photo, tap , then tap an application for sharing.
- To delete the photo, tap , then tap **Delete**.
- To play the video, tap .
- To play the slideshow, share or edit an image, or show more options, tap .




Changing Basic Phone Settings

Adjusting the volume

There are two ways to adjust the volume:

- Press the volume (+/-) button repeatedly to adjust the volume.
- Press the volume button once.
Drag the volume slider to adjust the volume.



Setting an alarm

1. From the Home screen, tap **Clock**.
2. Tap **Set alarm**.
3. To add an alarm, tap **Add alarm**.
4. To set the time, tap **Time**. Tap **▲** or **▼** to set the alarm time, and tap **Set**.
5. To set repeat mode, tap **Repeat**. Tap one or more options, then tap **OK**.
6. To set the ringtone, tap **Ringtone**. Tap an option, then tap **OK**.
7. To vibrate when the alarm sounds, check **Vibrate**.
8. To enter an alarm label, tap **Label**.
9. After all settings are complete, tap **OK**.

