

User manual

INSTRUCTIONS FOR RADIO CONTROL OPERATOR SINGLE ENTRY TRANSMITTER
MODEL NO.:X220-3

Read the following instructions thoroughly before using transmitter.

1. Remove the transmitter cover

Remove the access cover from the front of the transmitter by sliding the cover away from the top of the transmitter (Figure A). this will expose the battery. In order to facilitate the replacement of the battery.

2. The transmitter is rolling code encoding and transmitting, it will automatically and receiver code matching.

User can click the push button, A signal transmits out.
If the receiver successfully decoded, the receiver will normally work.



FIGURE A



Button batteries

FIGURE B

FCC NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS OR CHANGE TO THIS EQUIPMENT. SUCH MODIFICATIONS OR CHANGE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.