



MainMenu



1.All Menus

HD Radio: Converts to the last played radio mode.

SiriusXM: Listen to the channel

Android Auto: Runs android auto function.

Phone: Answer and make a call

Apple CarPlay: Runs Apple CarPlay function.

USB: Converts to the last played USB mode.

BT Music: Connect the mobile phone to play mobile audio

Navigation: Runs navigation function.

Audio Settings: Sound setting

enLIGHT10 RGB: Set light color

Camrea: Show the camera picture

Settings: Moves to the settings menu.

2. All Menus

HDMI: Display the picture and sound of connected peripherals

AV IN: Display the drive picture and sound

ACC.Control: Lamp control

DM Smart DSP: communicate with audiocontrol Bluetooth-enable devices

DM Control: audio control

APPS: apps displayed on the main page of the car

Display Off: The device enters the screen off state

HD Radio



【FM】: Click to switch FM mode.

【AM】: Click to switch AM mode.

【DX】 : Search the range of channels

【Analog seek】 : Channel search mode




Press **【****】**: Manual input channel



Press **【****】**: HD Radio Settings

Siriusxm



【For You】: Show some channels

【Categories】: Classification of channels

【My Collections】: Click on the channel that shows your collection



Press **【****】**: Tap to connect to wifi



Press **【****】**: Click on Search SiriusXM




Press **【****】**: Click to Listener, Account & Settings



Press **【****】**: Click to Related Content

Phone



【Favourites】: Click to display favorites

If you do not have any favorites, you can click on add favourites from contats to add favorites contacts




【Call log】: Show cell phone records


Click call log to display the call history, Click the three buttons on the left to switch between different modes of call logging。



【Contacts】: Tap to show your phone contacts
 A contact can be selected on the left, Click the number on the right to make a call,
 Click the five-pointed star to bookmark your contacts



【Phone Dial】: Click on the display keyboard to make a call




【Settings】: Click to display the device connected to the machine

Carplay

Note

- The Bluetooth source of the machine is not available when the carplay is connected.






Connect wireless carplay

1. press [settings-device-device list] to wireless carplay connection interface
2. Click [add a device] to search for available wireless carplay devices. Press the cancel button to stop the search.

3. Click the  button to connect to the paired device, and click the  button to delete the paired device.

BT Music

When Bluetooth is connected, the BT music icon will be highlighted. Click to play BT music.



Previous button

When it is pressed for a short time.

- Press the previous button to switch to the previous song(The playback progress does not exceed 5 seconds).
- Press the previous button, the currently playing song will restart (Play progress exceeds 5 seconds).

When it is pressed and held

- Rewind the currently playing song

Next button

When it is pressed for a short time.

- Press a button to cut to the next song


When it is pressed and held.

- Fast forward the currently playing song



List

- Click list to enter USB music player list




Search

- Tap to search for Bluetooth music name


Audio Settinngs

Press the [Audio Settings] icon interface to enter the Audio Settings interface.




Balance

- You can adjust the sound position by clicking the up / down / left / right arrow.




Equalizer

- You can set equalizer by yourself and save them




Factory EQ

- You can choose a Factory EQ model.




Advanced

- Reset Audio Settings to restore the default sound Settings



【Advanced-volume Settings】 You can set the volume of various sounds



enLIGHT10 RGB



You can set the color and brightness of the lamp.

Camrea

Press [Camera] interface show the camera picture.



Press[Settings-Camera-Camrea Setup]: You can set the picture of the camera.


Press[Reverse Camera Audio]: Sound output when you back up

Press[Mute Audio Play Back in Reverse]: Your reverse will be silent.

Press[Switch to Forward Camera after reverse]: When you're done backing up, another camera will appear

Settings

Press the [Settings] icon on the All Menus interface to enter the setup menu interface.




Press[Clock]: You can set the device time

Press[Beep]: You can set the size of the beep

Press[System Language]: You can set the system language

Press[Microphone]: You can set the output of the microphone sound



Press[Auto Brightness]: You can set auto brightness


Press[Display Brightness]: You can set the brightness of the screen

Press[Face Button Color]: You can set the color of the panel light

Press[Face Button Brightness]: You can set the color of the light on the engine panel

Press[System Highlights]: You can set the color of the selected apps


Press[Background]: You can set the background of the machine



Press[Quick Access Tab]: You can set up quick access to the apps

Press[Favourite Key]: You can set a favourite app, then through the five-pointed star button on the panel, can quickly access the app.

HDMI



HDMI shows you the sound and picture of external devices


AV IN



AV IN shows you the sound and picture of external devices

USB

When the USB disk is inserted, the USB music icon is highlighted. Click USB music to enter the USB music interface.



Pause

- You can pause the playing file
- Press [II] on screen .

Play

- Press [▶] on screen to play it again.

Previous button

When it is pressed for a short time.

- Press the previous button to switch to the previous video (playing progress does not exceed 5 seconds).
- Press the previous button, the currently playing video will restart (Play progress exceeds 5 seconds).

When it is pressed and held

- Rewind the currently playing video

Next button

When it is pressed for a short time.

- Press a button to cut to the next video

When it is pressed and held.

- Fast forward the currently playing video

Repeat

- Switch the repeat mode of the song: Repeat All, Repeat Folder, and Repeat Track.

File Button

- You can choose to play music, video or pictures

Search Button

- You can search for the usb file you are looking for

Android Auto



Connect wireless Android Auto

press [settings-device-device list] to wireless Android auto connection interface


Click [add a device] to search for available wireless Android auto devices. Press the cancel button to stop the search.

Acc.Control



This module can control the lighting

Apps



You can select the apps to display in the main menu

FCC Compliance Statement: This device complies with Part 15 of the FCC rules. Operation is subjected to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

The distance between user and products should be no less than 20cm.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to

radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.