


序号	版本号	描述	日期
1	V0	初版发行	2023.12.28
2			




T6 Counterpoint POS terminal
Operation Manual

78 mm

125 mm

Structure Description



Instructions

Power on /off
Power on: Press "Q" for 3.0 seconds, screen backlight appear, and terminal power on.
Power off: Press "Q" for several seconds, screen display "power off, please confirm or cancel", press confirm, power off.

Magnetic card
Please put the card magnetic strip towards to track device inside when swipe the card, it can support both directions. Make sure to swipe the card slowly and constantly.
Note: The transaction may fail if magnetic card type is damaged or swipe solution is wrong.

IC card
IC card slot locate in the bottom of the keypad. Keep the chip side up when swiping card, and insert IC card to the slot. The IC card should be inserted in the IC card slot during the transaction process.
Note: The transaction probably fail if IC card chip contact point is damaged or is oxidized.

Contactless card
Please put card close to the NFC area, and stay for one second, then remove card when you hear a "D" voice, showing as follow picture.

Turn-off Print Paper
Hold print paper, turn-off the print paper according to picture direction, keep direction from left to right, the strength should keep flat and equally during cutting paper.

Install Battery
1. Make sure the adapter is disconnected before installing the battery.
2. Disconnect the adapter.
3. Open battery cover.
4. Push battery connector connect with the white slot.
5. Put battery into the battery compartment.
6. Close battery cover.

Remove Battery
1. Power off.
2. Disconnect the adapter.
3. Open battery cover.
4. Take battery to the appropriate height.
5. Take out battery connector, and remove battery.

Install SIM
1. Open battery cover.
2. Insert SIM card as the picture show below.
(Note: chip side of card face terminal).

Remove SIM
1. Open battery cover.
2. Press SIM and remove out.

Print Process
1. Open power on/off cover.
2. Hold the print paper by hand, turn it down towards the direction as shown in the pic.
3. Close the print on/off cover and hear "hold" voice.

TE
LTE Band 5: 834-860MHz
LTE Band 7: 2630-2686MHz
LTE Band 18: 2130-2170MHz
LTE Band 41: 2496-2592MHz
4G/LTE: 2496-2592MHz
3G/3.5G: 2130-2170MHz
3G/3.5G: 2496-2592MHz
3G/3.5G: 2130-2170MHz
3G/3.5G: 2496-2592MHz
FCC ID: A2021451 supports
NFC: 13.56MHz
NFC: 13.56MHz

RU
LTE Band 5: 834-860MHz
LTE Band 7: 2630-2686MHz
LTE Band 18: 2130-2170MHz
LTE Band 41: 2496-2592MHz
4G/LTE: 2496-2592MHz
3G/3.5G: 2130-2170MHz
3G/3.5G: 2496-2592MHz
3G/3.5G: 2130-2170MHz
3G/3.5G: 2496-2592MHz
FCC ID: A2021451 supports
NFC: 13.56MHz
NFC: 13.56MHz

Common Fault Process

If the above solution can't solve the problem or have other questions, please contact maintenance.

Category	Fault	Reason	Solution
Power supply	The display does not power on	1. Check if battery is fully charged. 2. Check if battery is inserted correctly.	1. Connect AC power. 2. Recharge battery. 3. Reinsert battery. 4. Reinsert SIM card.
Screen	The screen shows green lines	1. Terminal crashed.	1. Restart the terminal.
	"Prompt: Card not ready, please remove the card"	1. Check if the card is inserted correctly. 2. Check if the card is a valid card. 3. Check if the card is a valid card.	1. Remove the card. 2. Reinsert the card. 3. Reinsert the card.
Customer reaction	"Please insert the card"	1. Check if the card is inserted correctly. 2. Check if the card is a valid card. 3. Check if the card is a valid card.	1. Remove the card. 2. Reinsert the card. 3. Reinsert the card.
Print	No prints when print	1. Check if the paper is loaded correctly. 2. Check if the paper is a valid paper. 3. Check if the paper is a valid paper.	1. Load the paper. 2. Reinsert the paper. 3. Reinsert the paper.

Company address: 118 Jiaolong Road, Xixi Industrial Park, Hangzhou, Zhejiang, China.
Manufacturer: Shenzhen Xingodu Technology Co., Ltd.
Factory address: 118 Jiaolong Road, Xixi Industrial Park, Hangzhou, Zhejiang, China.
Website: www.xingodu.com

Attention Of Installation And Operation

- Please follow the instruction strictly when install and connect the terminal.
- Do not damage the power line and power adapter. It can't be used any more if the power line or power adapter is damaged.
- Please check power supply socket whether complying with terminal and before insert the AC socket. Recommend to choose the line socket and grounding well.
- Please leave the terminal away from fluid, and forbidden splash into any fluid or electric conduction material, otherwise it will cause a short-circuit or damage to the terminal.
- Please do not insert any foreign material into any ports. It will damage the terminal seriously.
- Please connect the professional POS maintenance. When the terminal have fault, users or other non-qualified POS maintenance should not repair the terminal.
- Please do not touch the cutter knife in case of hurt when using the paper roll.
- Please use the standard print paper in case of paper jam or printer damage.
- Please do not shake or knock the terminal.
- Please do not use or abuse terminal by spray, painting, etc. in case of fire.
- Limited to responsible, or replace the terminal. Refrain to use the terminal in illegal way, otherwise will cause legal responsibility.

Component	Ph	Hg	Cd	CdH	Pb	PCB
PCB Components	0	0	0	0	0	0

Notes:
1) 0 means the content of this hazardous and noxious substance is all the homogeneous material of the component is below the requirement of EU T 1135/2006 standard.
2) X means the content of this hazardous and noxious substance is all the homogeneous material is higher than the requirements of EU T 1135/2006 standard, but the components marked by "X" in the above form are all due to the current industry technology level and cannot make the substitution of the hazardous and noxious substances or elements.

Environmental protection indication:
For the products which arrives or exceeds the use life, should be recycled used according to "The Management of Electronic and Information Products" current demand actively.

Packing list

No.	Item	Quantity
1	Main body	1
2	Operation Manual	1
3	Battery	1
4	Adapter	1

Announcement
Shenzhen Xingodu Technology Co., Ltd reserves the right to modify this manual without prior notice, and continuously improve the accuracy, adaptability and completeness of the information contained in this manual.
Shenzhen Xingodu Technology Co., Ltd does not accept any legal responsibility for the adverse consequences caused by using the product not in accordance with the manual or using accessories which are not supplied by Shenzhen Xingodu Technology Co., Ltd.
This manual is copyrighted by © Shenzhen Xingodu Technology Co., Ltd.

RF Exposure Compliance
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions to ensure proper RF exposure compliance. This transmitter must not be used in conjunction with any other antenna or transmitter. The device was tested in compliance with FCC SAR limit, Externally limit 4.0W/kg, 10g SAR, with 0 mm.

FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.


If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

技术要求:

- 1. 材质: 105g铜版纸
- 2. 印刷: 四色印刷
- 3. 成型尺寸: 78x125mm
- 4. 公差: ±1
- 5. 装订方式: 风琴折

第三视角投影





深圳市新国都支付技术有限公司

图纸	A4	单位	mm
设计	李艳华		
审核	罗果	比例	1:3
批 准	何杰锋	料 号	XXXXXXXXX
FORM-R&D-216 REV. A		版本号	V0
		第 1 页	共 1 页

T6快速操作手册(FCC 认证)

材 料	105g铜版纸
完成日期	2023.12.28