

# WISARD-550 Operators Guide

FCC ID: XE3-WISARD550

IC: 8347A-WISARD550

## 1 Overview

The WISARD-550 is a hand held data collector. It is normally held in the left or right hand of the operator as shown to the right.



## 2 Operation

### Turn the unit on or off:

Press the ON/OFF switch located to the left of display screen or press the blue ON/OFF button on the lower keypad in the upper left corner.

### Booting up the WISARD:

At the intro screen, press enter “File already exists continue Y/N?” appears then press enter once more and select the file

### Enter employee number:

Enter your 6 digit employee number at the prompt and press <ENTER>.

**Tag/shelf entry:**

Scan the barcode on the bottom of the tag or enter the shelf number at the shelf prompt and press <ENTER>.

**Review:**

Press the left arrow key once on the lower key pad to search the last entry.

**Recording totals:**

At the last entry press <END> once and your shelf totals will be displayed. Write the totals on the tag if applicable.

**Search entry/shelf/tag:**

In review mode (as described above) there are four options:

- 1) Press the left arrow key repeatedly to locate the entry.
- 2) Press the up arrow key up to search down by shelf, once the shelf is found, press the left or right arrow key to find the entry.
- 3) Press <SEARCH> on the lower key pad and enter the 4 digit tag number and 2 digit shelf number. Then follow step 2 to find the entry.
- 4) Press <ALT> and then <SEARCH> to search for a specific SKU or UPC as opposed to looking by tag/shelf.

**Searching totals:**

To recall totals from a previous shelf, enter review mode as described above then press up arrow key to find the shelf. Then press <TOTAL> on lower key pad.

To view the totals of the current shelf, press <TOTAL>.

Press <END> when done to return to normal data entry.

**Delete entry:**

Enter review mode as described above. Locate the entry (UPC/SKU will be highlighted). Press <ALT> then press <DELETE> on the lower keypad. Press <YES> at the “Are you sure? Y/N” prompt.

**Delete shelf:**

Enter review mode as described above. Search using the up arrow key to locate the shelf. Press <ALT> then press <DELETE>. Press <YES> when prompted.

**Delete tag:**

Enter review mode as described above. Use <SEARCH> or the up arrow key to locate the shelf. Press <ALT> then press <DELETE>. A password prompt will appear. Management will provide the requested password.

**Ending a tag:**

Press <END> once to record your last shelf totals for the tag. Press <end> once more for the shelf prompt. Press <END> once more to view the grand totals for the tag. Press <END> again to end the tag. The display screen will display a tag prompt again.

**Legend of displayed symbols:**

e – Entry mode (data entry, key or scan the product code)

qe – Auto quantity one entry. (only one entry per scan)

r – Review mode (use the left arrow key to enter into this mode)

m – Modify (use to highlight and change an entry)

### 3 FCC Part 15 Information to User

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### 4 RF Exposure Limits

To satisfy FCC RF exposure compliance requirements, this device should be used in hand-held, hand operated configurations only. While transmitting, the device and its antenna must maintain a separation distance of 20 cm or more from the person's body, except for the hand and wrists, to satisfy RF exposure compliance.

This device is designed to be used in a person's hands and its operating configurations do not support normal transmissions while it is carried in pockets or holsters next to a persons' body.