

# User Operation Manual

## KB-6133 MINI Bluetooth Keyboard

Work with iPhone 4.0/IPad/  
Ps3/Smart Phone/PC/HTPC



### 7.Bluetooth Keyboard Connect Ipad Instruction:

1. Start IPAD, enter the main interface.
2. Click the "Settings" enter the menu and choose the "bluetooth"at the left menu.



3. Adjust the Bluetooth to "On"status.



4. Open the Bluetooth Keyboard, the light on the keyboard will twinkle, Click on the "Bluetooth"on IPAD when the column shows "not connected" status at the same time.



6

- 5.The IPAD will search the bluetoothkeyboard signal, there will be a dialog box. Please enter the numbers which show on the dialog box, then click "enter"on the Bluetooth keyboard.



- 6.Click "ok" on the dialog box.



7. The "Bluetooth" column will show "connected" once the connect is success.

The product apply the Frequency Hopping Technology, between 2402-2480 MHz, 79 frequency hopping channels, not supported AFH.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received,

7

including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

8

### CHIN FAI ELECTRONICS COMPANY

Factory Address: Building 2c-2d, Yingfeng Industrial Park, Sanhe Economic Development Zone, Huiyang District, Huizhou City, Guangdong Province.  
WWW. Silicon-rubber.com  
Customer Service Phone: 400-888-2248



### Welcome to use the bluetooth keyboard.

#### 1.Package contents:

Your Bluetooth Keyboard package contains the following:

Bluetooth Keyboard-----1  
User Operation Manual-----1  
Charging Data Cable-----1  
(The Charging Data Cable is for charging, not apply for data exchange.)

Note: If you find any of the above is missing, please contact the supplier for replacement.

#### 2.Product structure:



1

#### 3.How to use the bluetooth keyboard:

- 1.Bluetooth Keyboard is not available for the following conditions:



The products can not come into contact with sharp objects.



The product can not come into contact with oil or chemicals.



Do not put heavy objects on top of the product.



Do not expose the product to fire source.



#### 4.Safety tips:

- 1.The product complies with FCC and CE certification and ROHS standard.
- 2.If the bluetooth keyboard is not operated in accordance with the bluetooth keyboard instructions, it will cause the keyboard not to work properly.
- 3.Note:

Anyone who randomly changes or updates the devices that have not been approved by the manufacturer will have his right to use the equipment canceled.

#### 5.Work Environment tip:

Some experts believe that the use of the keyboard can cause pain in the hands, soreness in the arms and the back. If the user feels pain, numbness or fatigue, please pay attention to appropriate rest and relaxation.

#### 6.Bluetooth Keyboard Connect Iphone4 Instruction:

1. Start iPhone4, enter the main interface.



2

2. Click the "Settings" enter the menu and choose "General".



3. Click on the "Bluetooth" menu.



4. Adjust the Bluetooth to "On"status.



- 5.Open the Bluetooth Keyboard, the light on the keyboard will twinkle, Click on the "Bluetooth" on iPhone4 when the column shows "not connected" status at the same time.



- 6.The iPhone4 will search the bluetooth keyboard signal, there will be a dialog box. Please enter the numbers which show on the dialog box, then click "enter" on the Bluetooth keyboard.



7. The "Bluetooth" column will show "connected" once the connect is success.



3

4

5