

Input audio signal by the SD card, through the IC 1088 mixings, and adjust the IC QN8027 to change transmitting frequency, then the RF signal via the antenna transmitting .

1. working voltage:DC12V-24V
2. IC AX2008 crystal oscillator: 12MHz
3. transmitter frequency: 88.1 MHz ~107.9MHz