



NTNV-n77(3700-3980)-PC2-30-20-L-DFT-QPSK-Inner_1RB_Right-10
00-3000-PASS

NTNV-n77(3700-3980)-PC2-30-20-L-DFT-QPSK-Inner_1RB_Right-300
0-6000-PASS

NTNV-n77(3700-3980)-PC2-30-20-L-DFT-QPSK-Inner_1RB_Right-60
00-26000-PASS

NTNV-n77(3700-3980)-PC2-30-20-L-DFT-QPSK-Inner_1RB_Right-260
00-40000-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Left-0.15
-30-PASS



NTNV-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Left-100
0-3000-PASS


NTNV-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Left-600
0-26000-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Left-260
00-40000-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Right-0.
15-30-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Right-30-
1000-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Right-1
000-3000-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS




NTVN-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Right-6000-26000-PASS




NTVN-n77(3700-3980)-PC2-30-20-M-DFT-BPSK-Inner_1RB_Right-26000-40000-PASS



NTVN-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS




NTVN-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTVN-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTVN-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS





NTVN-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS



NTVN-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Left-6000-26000-PASS


NTNV-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Left-26
000-40000-PASS



NTNV-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Right-0.0
09-0.15-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Right-0.
15-30-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Right-30
-1000-PASS


NTNV-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Right-1
000-3000-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Right-30
00-6000-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Right-6
000-26000-PASS

NTNV-n77(3700-3980)-PC2-30-20-M-DFT-QPSK-Inner_1RB_Right-26
000-40000-PASS




NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Left-0.15-
30-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Left-6000
-26000-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Left-260
00-40000-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS


NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Right-0.
15-30-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Right-30-
1000-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Right-10
00-3000-PASS


NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Right-60
00-26000-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-BPSK-Inner_1RB_Right-26
000-40000-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Left-0.15
-30-PASS



NTVN-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTVN-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTVN-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS



NTVN-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Left-6000-26000-PASS




NTVN-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Left-26000-40000-PASS



NTVN-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Right-0.09-0.15-PASS



NTVN-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS




NTVN-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Right-30-1000-PASS


NTNV-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Right-1
000-3000-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Right-30
00-6000-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Right-6
000-26000-PASS

NTNV-n77(3700-3980)-PC2-30-20-H-DFT-QPSK-Inner_1RB_Right-26
000-40000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Left-0.00
9-0.15-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Left-0.15-
30-PASS


NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Left-30-1
000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS


NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Left-6000
-26000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Left-260
00-40000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Right-0.
15-30-PASS



NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Right-30-
1000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Right-10
00-3000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Right-300
0-6000-PASS


NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Right-60
00-26000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-BPSK-Inner_1RB_Right-260
00-40000-PASS



NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Left-0.15-
30-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Left-30-
1000-PASS


NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Left-1000
-3000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Left-300
0-6000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Left-6000
-26000-PASS




NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Left-260
00-40000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Right-0.0
09-0.15-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Right-0.
15-30-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Right-30-
1000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Right-10
00-3000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Right-300
0-6000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Right-60
00-26000-PASS

NTNV-n77(3700-3980)-PC2-30-25-L-DFT-QPSK-Inner_1RB_Right-260
00-40000-PASS


NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Left-0.15
-30-PASS

NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS


NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Left-100
0-3000-PASS

NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS


NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Left-600
0-26000-PASS

NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Left-260
00-40000-PASS

NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS



NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Right-1000-3000-PASS



NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Right-3000-6000-PASS



NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Right-6000-26000-PASS




NTNV-n77(3700-3980)-PC2-30-25-M-DFT-BPSK-Inner_1RB_Right-26000-40000-PASS



NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Left-0.09-0.15-PASS



NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Left-6000-26000-PASS




NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Left-26000-40000-PASS



NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Right-0.09-0.15-PASS



NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS




NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Right-30-1000-PASS


NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Right-1
000-3000-PASS

NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Right-30
00-6000-PASS

NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Right-6
000-26000-PASS

NTNV-n77(3700-3980)-PC2-30-25-M-DFT-QPSK-Inner_1RB_Right-26
000-40000-PASS

NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Left-0.15-
30-PASS

NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS


NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS


NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS

NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Left-6000
-26000-PASS

NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Left-260
00-40000-PASS

NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS

NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Right-0.
15-30-PASS

NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Right-30-
1000-PASS

NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Right-10
00-3000-PASS

NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS




NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Right-6000-26000-PASS




NTNV-n77(3700-3980)-PC2-30-25-H-DFT-BPSK-Inner_1RB_Right-26000-40000-PASS



NTNV-n77(3700-3980)-PC2-30-25-H-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n77(3700-3980)-PC2-30-25-H-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n77(3700-3980)-PC2-30-25-H-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n77(3700-3980)-PC2-30-25-H-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n77(3700-3980)-PC2-30-25-H-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS



NTNV-n77(3700-3980)-PC2-30-25-H-DFT-QPSK-Inner_1RB_Left-6000-26000-PASS