





NTNV-n78(3450-3550)-PC2-30-50-M-DFT-BPSK-Inner\_1RB\_Left-300  
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-50-M-DFT-BPSK-Inner\_1RB\_Left-600  
0-20000-PASS

NTNV-n78(3450-3550)-PC2-30-50-M-DFT-BPSK-Inner\_1RB\_Left-200  
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-50-M-DFT-BPSK-Inner\_1RB\_Right-0.0  
09-0.15-PASS


NTNV-n78(3450-3550)-PC2-30-50-M-DFT-BPSK-Inner\_1RB\_Right-0.15-30-PASS




NTNV-n78(3450-3550)-PC2-30-50-M-DFT-BPSK-Inner\_1RB\_Right-30-1000-PASS




NTNV-n78(3450-3550)-PC2-30-50-M-DFT-BPSK-Inner\_1RB\_Right-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-50-M-DFT-BPSK-Inner\_1RB\_Right-3000-6000-PASS




NTNV-n78(3450-3550)-PC2-30-50-M-DFT-BPSK-Inner\_1RB\_Right-6000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-50-M-DFT-BPSK-Inner\_1RB\_Right-2000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Left-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Left-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Left-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Left-1000-3000-PASS




NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Left-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Left-6000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Left-20000-40000-PASS




NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Right-0.09-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Right-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Right-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Right-1000-3000-PASS





NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Right-3000-6000-PASS




NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Right-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-50-M-DFT-QPSK-Inner\_1RB\_Right-20000-40000-PASS


NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Left-0.0  
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Left-0.15-  
30-PASS


NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Left-30-  
1000-PASS

NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Left-1000  
-3000-PASS

NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Left-300  
0-6000-PASS


NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Left-6000  
-20000-PASS

NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Left-200  
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Right-0.0  
09-0.15-PASS


NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Right-0.  
15-30-PASS

NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Right-30-  
1000-PASS


NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Right-10  
00-3000-PASS

NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Right-30  
00-6000-PASS

NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Right-60  
00-20000-PASS

NTNV-n78(3450-3550)-PC2-30-50-H-DFT-BPSK-Inner\_1RB\_Right-20  
000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Left-0.0  
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Left-0.15  
-30-PASS




NTNV-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Left-30-1000-PASS




NTNV-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Left-1000-0-3000-PASS




NTNV-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Left-3000-0-6000-PASS



NTNV-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Left-6000-0-20000-PASS



NTNV-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Left-20000-00-40000-PASS



NTNV-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Right-0.009-0.15-PASS





NTNV-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Right-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Right-30-1000-PASS


NTVN-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Right-1  
000-3000-PASS

NTVN-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Right-30  
00-6000-PASS

NTVN-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Right-6  
000-20000-PASS

NTVN-n78(3450-3550)-PC2-30-50-H-DFT-QPSK-Inner\_1RB\_Right-20  
000-40000-PASS

NTVN-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Left-0.00  
9-0.15-PASS

NTVN-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Left-0.15-  
30-PASS


NTVN-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Left-30-1  
000-PASS

NTVN-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Left-1000  
-3000-PASS


NTNV-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Left-300  
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Left-6000  
-20000-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Left-200  
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Right-0.0  
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Right-0.  
15-30-PASS


NTNV-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Right-30-  
1000-PASS


NTNV-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Right-10  
00-3000-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Right-300  
0-6000-PASS


NTNV-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Right-60  
00-20000-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-BPSK-Inner\_1RB\_Right-200  
00-40000-PASS




NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Left-0.0  
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Left-0.15-  
30-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Left-30-  
1000-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Left-1000  
-3000-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Left-300  
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Left-6000  
-20000-PASS



NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Left-200  
00-40000-PASS


NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Right-0.0  
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Right-0.  
15-30-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Right-30-  
1000-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Right-10  
00-3000-PASS


NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Right-300  
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Right-60  
00-20000-PASS

NTNV-n78(3450-3550)-PC2-30-60-L-DFT-QPSK-Inner\_1RB\_Right-200  
00-40000-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Left-0.0  
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Left-0.15  
-30-PASS

NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Left-30-  
1000-PASS

NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Left-100  
0-3000-PASS


NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Left-300  
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Left-600  
0-20000-PASS

NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Left-200  
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Right-0.0  
09-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Right-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Right-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Right-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Right-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Right-6000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-60-M-DFT-BPSK-Inner\_1RB\_Right-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Left-0.09-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Left-0.15-30-PASS




NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Left-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Left-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Left-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Left-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Left-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Right-0.09-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Right-0.15-30-PASS




NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Right-30-1000-PASS




NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Right-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Right-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Right-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-60-M-DFT-QPSK-Inner\_1RB\_Right-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Left-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Left-0.15-30-PASS






NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Left-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Left-1000-3000-PASS


NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Left-300  
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Left-6000  
-20000-PASS


NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Left-200  
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Right-0.0  
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Right-0.  
15-30-PASS

NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Right-30-  
1000-PASS

NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Right-10  
00-3000-PASS


NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Right-30  
00-6000-PASS




NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Right-6000-00000-PASS



NTNV-n78(3450-3550)-PC2-30-60-H-DFT-BPSK-Inner\_1RB\_Right-2000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Left-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Left-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Left-30-1000-PASS




NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Left-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Left-3000-0-6000-PASS



NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Left-6000-0-20000-PASS




NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Left-200 00-40000-PASS



NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Right-0.0 09-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Right-0. 15-30-PASS



NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Right-30- 1000-PASS




NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Right-1 000-3000-PASS




NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Right-30 00-6000-PASS




NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Right-6 000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-60-H-DFT-QPSK-Inner\_1RB\_Right-20 000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Left-0.00  
9-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Left-0.15-  
30-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Left-30-1  
000-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Left-1000  
-3000-PASS


NTNV-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Left-300  
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Left-6000  
-20000-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Left-200  
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Right-0.0  
09-0.15-PASS



NTVN-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Right-0.15-30-PASS



NTVN-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Right-30-1000-PASS




NTVN-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Right-1000-3000-PASS



NTVN-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Right-3000-6000-PASS



NTVN-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Right-6000-20000-PASS




NTVN-n78(3450-3550)-PC2-30-70-L-DFT-BPSK-Inner\_1RB\_Right-20000-40000-PASS



NTVN-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Left-0.09-0.15-PASS



NTVN-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Left-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Left-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Left-1000-3000-PASS




NTNV-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Left-3000-0-6000-PASS



NTNV-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Left-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Left-20000-0-40000-PASS



NTNV-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Right-0.09-0.15-PASS




NTNV-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Right-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Right-30-1000-PASS


NTNV-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Right-10  
00-3000-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Right-300  
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Right-60  
00-20000-PASS

NTNV-n78(3450-3550)-PC2-30-70-L-DFT-QPSK-Inner\_1RB\_Right-200  
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Left-0.0  
09-0.15-PASS


NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Left-0.15  
-30-PASS

NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Left-30-  
1000-PASS


NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Left-100  
0-3000-PASS


NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Left-300  
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Left-600  
0-20000-PASS

NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Left-200  
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Right-0.0  
09-0.15-PASS


NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Right-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Right-30-1000-PASS




NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Right-1.000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Right-30.00-6000-PASS




NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Right-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-DFT-BPSK-Inner\_1RB\_Right-2000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Left-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Left-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Left-30-1000-PASS







NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Left-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Left-3000-6000-PASS





NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Left-6000-20000-PASS


NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Left-20  
000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Right-0.0  
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Right-0.  
15-30-PASS

NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Right-30  
-1000-PASS

NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Right-1  
000-3000-PASS

NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Right-30  
00-6000-PASS

NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Right-6  
000-20000-PASS

NTNV-n78(3450-3550)-PC2-30-70-M-DFT-QPSK-Inner\_1RB\_Right-20  
000-40000-PASS


NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Left-0.0  
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Left-0.15-  
30-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Left-30-  
1000-PASS



NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Left-1000  
-3000-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Left-300  
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Left-6000  
-20000-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Left-200  
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Right-0.0  
09-0.15-PASS


NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Right-0.  
15-30-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Right-30-  
1000-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Right-10  
00-3000-PASS


NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Right-30  
00-6000-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Right-60  
00-20000-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-DFT-BPSK-Inner\_1RB\_Right-20  
000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Left-0.0  
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Left-0.15  
-30-PASS



NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Left-30-1000-PASS




NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Left-1000-3000-PASS




NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Left-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Left-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Left-20000-40000-PASS




NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Right-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Right-0.15-30-PASS




NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Right-30-1000-PASS


NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Right-1  
000-3000-PASS

NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Right-30  
00-6000-PASS


NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Right-6  
000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-70-H-DFT-QPSK-Inner\_1RB\_Right-20  
000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Left-0.00  
9-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Left-0.15-  
30-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Left-30-1  
000-PASS




NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Left-1000  
-3000-PASS


NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Left-300  
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Left-6000  
-20000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Left-200  
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Right-0.0  
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Right-0.  
15-30-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Right-30-  
1000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Right-10  
00-3000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Right-300  
0-6000-PASS


NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Right-60  
00-20000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-BPSK-Inner\_1RB\_Right-200  
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Left-0.0  
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Left-0.15-  
30-PASS



NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Left-30-  
1000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Left-1000  
-3000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Left-300  
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Left-6000  
-20000-PASS


NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Left-200  
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Right-0.0  
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Right-0.  
15-30-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Right-30-  
1000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Right-10  
00-3000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Right-300  
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Right-60  
00-20000-PASS

NTNV-n78(3450-3550)-PC2-30-80-L-DFT-QPSK-Inner\_1RB\_Right-200  
00-40000-PASS