



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-0.15
-30-PASS

NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS


NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-100
0-3000-PASS

NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS


NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-600
0-20000-PASS

NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-200
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-0.09-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-6000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-0.09-0.15-PASS





NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-30-1000-PASS


NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-1
000-3000-PASS

NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-30
00-6000-PASS

NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-6
000-20000-PASS

NTNV-n78(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-20
000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS


NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-0.15-
30-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS


NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-6000
-20000-PASS


NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-200
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-0.
15-30-PASS


NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-30-
1000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-10
00-3000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS




NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-6000-00000-PASS



NTNV-n78(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-2000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-30-1000-PASS







NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS





NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-6000-20000-PASS


NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-200
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-0.0
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-0.
15-30-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-30-
1000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-1
000-3000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-30
00-6000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-6
000-20000-PASS

NTNV-n78(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-20
000-40000-PASS


NTNV-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-0.00
9-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-0.15-
30-PASS

NTNV-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-30-1
000-PASS


NTNV-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS

NTNV-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-6000
-20000-PASS

NTNV-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-200
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS



NTVN-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS




NTVN-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-30-1000-PASS




NTVN-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-1000-3000-PASS



NTVN-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-3000-6000-PASS



NTVN-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-6000-20000-PASS




NTVN-n78(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-20000-40000-PASS



NTVN-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-0.09-0.15-PASS



NTVN-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-3000-0-6000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-20000-0-40000-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-0.09-0.15-PASS




NTNV-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-30-1000-PASS


NTNV-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-10
00-3000-PASS

NTNV-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-300
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-60
00-20000-PASS

NTNV-n78(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-200
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-0.15
-30-PASS

NTNV-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS

NTNV-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-100
0-3000-PASS


NTNV-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS

NTNV-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-600
0-20000-PASS

NTNV-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-200
00-40000-PASS

NTNV-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS


NTNV-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS




NTNV-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-30-1000-PASS




NTNV-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-1-000-3000-PASS




NTNV-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-30-00-6000-PASS




NTVN-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-6000-20000-PASS




NTVN-n78(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-2000-40000-PASS



NTVN-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-0.09-0.15-PASS



NTVN-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTVN-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS




NTVN-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTVN-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS



NTVN-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-6000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-20000-40000-PASS




NTNV-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-0.09-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-1.000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-30.00-6000-PASS



NTNV-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-6.000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-20.000-40000-PASS





NTNV-n78(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS


NTNV-n78(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-6000
-20000-PASS



NTNV-n78(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS


NTNV-n78(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-0.
15-30-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-30-
1000-PASS


NTNV-n78(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-10
00-3000-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-60
00-20000-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-20
000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-0.15
-30-PASS



NTNV-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-0.09-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS





NTNV-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-30-1000-PASS


NTVN-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-1
000-3000-PASS

NTVN-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-30
00-6000-PASS

NTVN-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-6
000-20000-PASS


NTVN-n78(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-20
000-40000-PASS

NTVN-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTVN-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-0.1
5-30-PASS

NTVN-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS

NTVN-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-100
0-3000-PASS


NTNV-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-30
00-6000-PASS

NTNV-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-600
0-20000-PASS


NTNV-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-20
000-40000-PASS

NTNV-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-0.
009-0.15-PASS

NTNV-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-0
.15-30-PASS

NTNV-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-30
-1000-PASS

NTNV-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-1
000-3000-PASS

NTNV-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS




NTNV-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-6000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-2000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-0.1-5-30-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-6000-20000-PASS




NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-20000-40000-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-0009-0.15-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-1000-3000-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-3000-6000-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-6000-20000-PASS



NTNV-n78(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-20000-40000-PASS

Frequency Stability

Test Result

Voltage											
Band	SCS	Bandwidth	Modulation	Channel	RB Config	Voltage (Vdc)	Temperature (°C)	Deviation (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
n78(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	VL	NT	-5.73	-0.001637	±2.5	PASS
n78(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	VN	NT	8.98	0.002566	±2.5	PASS
n78(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	VH	NT	2	0.000571	±2.5	PASS

Temperature											
Band	SCS	Bandwidth	Modulation	Channel	RB Config	Voltage (Vdc)	Temperature (°C)	Deviation (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
n78(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	-30	-8.02	-0.002291	±2.5	PASS
n78(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	-20	-6.35	-0.001814	±2.5	PASS
n78(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	-10	-0.67	-0.000191	±2.5	PASS
n78(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	0	-14.94	-0.004269	±2.5	PASS
n78(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	10	-2.11	-0.000603	±2.5	PASS
n78(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	20	8.52	0.002434	±2.5	PASS
n78(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	30	-10.03	-0.002866	±2.5	PASS
n78(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	40	-12.85	-0.003671	±2.5	PASS
n78(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	50	5.48	0.001566	±2.5	PASS

***** End of the Report *****