







NTNV-n78(3700-3800)-PC2-30-80-L-DFT-QPSK-Inner_1RB_Left-260
00-40000-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-DFT-QPSK-Inner_1RB_Right-0.0
09-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-DFT-QPSK-Inner_1RB_Right-0.
15-30-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-DFT-QPSK-Inner_1RB_Right-30-
1000-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-DFT-QPSK-Inner_1RB_Right-10
00-3000-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-DFT-QPSK-Inner_1RB_Right-300
0-6000-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-DFT-QPSK-Inner_1RB_Right-60
00-26000-PASS

NTNV-n78(3700-3800)-PC2-30-80-L-DFT-QPSK-Inner_1RB_Right-260
00-40000-PASS


NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-0.15
-30-PASS

NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS


NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-100
0-3000-PASS

NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS


NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-600
0-26000-PASS

NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-260
00-40000-PASS

NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-1000-3000-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-3000-6000-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-6000-26000-PASS




NTNV-n78(3700-3800)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-0.09-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-6000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-0.09-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS





NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-30-1000-PASS


NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-1
000-3000-PASS


NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-30
00-6000-PASS

NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-6
000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-26
000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-0.15-
30-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS



NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-6000
-26000-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-260
00-40000-PASS


NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-0.
15-30-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-30-
1000-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-10
00-3000-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS




NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-6000-26000-PASS




NTNV-n78(3700-3800)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-30-1000-PASS









NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS





NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-6000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-260
00-40000-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-0.0
09-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-0.
15-30-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-30-
1000-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-1
000-3000-PASS

NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-30
00-6000-PASS


NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-6
000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-26
000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-0.00
9-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-0.15-
30-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-30-1
000-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-6000
-26000-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-260
00-40000-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS


NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-0.
15-30-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-30-
1000-PASS


NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-10
00-3000-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-300
0-6000-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-60
00-26000-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-260
00-40000-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-0.15-
30-PASS




NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-3000-0-6000-PASS



NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-6000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-26000-00-40000-PASS



NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-0.0-09-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS




NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-30-1000-PASS


NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-10
00-3000-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-300
0-6000-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-60
00-26000-PASS

NTNV-n78(3700-3800)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-260
00-40000-PASS

NTNV-n78(3700-3800)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS


NTNV-n78(3700-3800)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-0.15
-30-PASS

NTNV-n78(3700-3800)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS


NTNV-n78(3700-3800)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-100
0-3000-PASS



NTNV-n78(3700-3800)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-600
0-26000-PASS




NTNV-n78(3700-3800)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS




NTNV-n78(3700-3800)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-30-1000-PASS

NTNV-n78(3700-3800)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS




NTNV-n78(3700-3800)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-6000-PASS




NTNV-n78(3700-3800)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-26000-PASS



NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-0.09-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-6000-26000-PASS




NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-0.09-0.15-PASS




NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-1.000-3000-PASS




NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-30.00-6000-PASS



NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-6.000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-26.000-40000-PASS


NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-0.15-
30-PASS

NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS


NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS

NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS


NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-6000
-26000-PASS

NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-260
00-40000-PASS

NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-10-00-3000-PASS



NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-30-00-6000-PASS



NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-60-00-26000-PASS




NTNV-n78(3700-3800)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-26-000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-0.09-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS



NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-6000-26000-PASS



NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-26000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-30-1000-PASS


NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-1
000-3000-PASS

NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-30
00-6000-PASS

NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-6
000-26000-PASS

NTNV-n78(3700-3800)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-26
000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS


NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-0.1
5-30-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-30
1000-PASS


NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-100
0-3000-PASS




NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-30
00-6000-PASS



NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-600
0-26000-PASS



NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-26
000-40000-PASS



NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-0.
009-0.15-PASS



NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-0
.15-30-PASS





NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-30
-1000-PASS





NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-1
000-3000-PASS



NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS






NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-6
000-26000-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-26
000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-0.
009-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-0.1
5-30-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-30
-1000-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-100
0-3000-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-30
00-6000-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-600
0-26000-PASS


NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-26
000-40000-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-0.
009-0.15-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-0
.15-30-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-30
-1000-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-1
000-3000-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-30
00-6000-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-6
000-26000-PASS

NTNV-n78(3700-3800)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-26
000-40000-PASS

Frequency Stability

Test Result

Voltage											
Band	SCS	Bandwidth	Modulation	Channel	RB Config	Voltage (Vdc)	Temperature (°C)	Deviation (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
n78(3700-3800)	30	100	DFT-QPSK	M	Outer_Full	VL	NT	-3.95	-0.001053	±2.5	PASS
n78(3700-3800)	30	100	DFT-QPSK	M	Outer_Full	VN	NT	1.64	0.000437	±2.5	PASS
n78(3700-3800)	30	100	DFT-QPSK	M	Outer_Full	VH	NT	-6.14	-0.001637	±2.5	PASS

Temperature											
Band	SCS	Bandwidth	Modulation	Channel	RB Config	Voltage (Vdc)	Temperature (°C)	Deviation (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
n78(3700-3800)	30	100	DFT-QPSK	M	Outer_Full	NV	-30	-5.67	-0.001512	±2.5	PASS
n78(3700-3800)	30	100	DFT-QPSK	M	Outer_Full	NV	-20	-13.83	-0.003688	±2.5	PASS
n78(3700-3800)	30	100	DFT-QPSK	M	Outer_Full	NV	-10	-3.03	-0.000808	±2.5	PASS
n78(3700-3800)	30	100	DFT-QPSK	M	Outer_Full	NV	0	-0.33	-0.000805	±2.5	PASS
n78(3700-3800)	30	100	DFT-QPSK	M	Outer_Full	NV	10	-15.98	-0.004261	±2.5	PASS
n78(3700-3800)	30	100	DFT-QPSK	M	Outer_Full	NV	20	-16.75	-0.004467	±2.5	PASS
n78(3700-3800)	30	100	DFT-QPSK	M	Outer_Full	NV	30	-4.63	-0.001235	±2.5	PASS
n78(3700-3800)	30	100	DFT-QPSK	M	Outer_Full	NV	40	-3.29	-0.000877	±2.5	PASS
n78(3700-3800)	30	100	DFT-QPSK	M	Outer_Full	NV	50	-10.56	-0.002816	±2.5	PASS

***** End of the Report *****