




NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-0.15
-30-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-100
0-3000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-600
0-20000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Left-200
00-40000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-0.
15-30-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-30.
1000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-1
000-3000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-6
000-20000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-BPSK-Inner_1RB_Right-20
000-40000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-0.0
09-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-0.15
-30-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-6000-20000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Left-20000-40000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-0.09-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-1
000-3000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-30
00-6000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-6
000-20000-PASS



NTNV-n77(3450-3550)-PC2-30-80-M-DFT-QPSK-Inner_1RB_Right-20
000-40000-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-0.15-
30-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-6000
-20000-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Left-200
00-40000-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-0.
15-30-PASS




NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-30-
1000-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-10
00-3000-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS



NTVN-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-60
00-20000-PASS



NTVN-n77(3450-3550)-PC2-30-80-H-DFT-BPSK-Inner_1RB_Right-20
000-40000-PASS



NTVN-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-0.0
09-0.15-PASS



NTVN-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-0.15
-30-PASS



NTVN-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-30-
1000-PASS



NTVN-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-100
0-3000-PASS



NTVN-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-300
0-6000-PASS



NTVN-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-600
0-20000-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Left-200 00-40000-PASS

NTNV-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-0.0 09-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-0. 15-30-PASS

NTNV-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-30. 1000-PASS



NTNV-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-1. 000-3000-PASS

NTNV-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-30. 00-6000-PASS




NTNV-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-6. 000-20000-PASS

NTNV-n77(3450-3550)-PC2-30-80-H-DFT-QPSK-Inner_1RB_Right-20. 000-40000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-0.00
9-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-0.15-
30-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-30-1
000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-6000
-20000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Left-200
00-40000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS



NTVN-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS



NTVN-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-30-1000-PASS



NTVN-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-1000-3000-PASS



NTVN-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-3000-6000-PASS



NTVN-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-6000-20000-PASS



NTVN-n77(3450-3550)-PC2-30-90-L-DFT-BPSK-Inner_1RB_Right-20000-40000-PASS



NTVN-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-0.09-0.15-PASS



NTVN-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-300-0-6000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-6000-20000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Left-200-00-40000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-0.0-09-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-10
00-3000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-300
0-6000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-60
00-20000-PASS



NTNV-n77(3450-3550)-PC2-30-90-L-DFT-QPSK-Inner_1RB_Right-200
00-40000-PASS



NTNV-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-0.15
-30-PASS



NTNV-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-30
1000-PASS



NTNV-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-100
0-3000-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-600
0-20000-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Left-200
00-40000-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-0.
15-30-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-30-
1000-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-1
000-3000-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-6000-20000-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-BPSK-Inner_1RB_Right-2000-40000-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-0.09-0.15-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-100-0-3000-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-30-00-6000-PASS



NTVN-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-600-0-20000-PASS



NTNV-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Left-20000-40000-PASS



NTNV-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-009-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-015-30-PASS



NTNV-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-1000-3000-PASS



NTNV-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-3000-6000-PASS




NTNV-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-6000-20000-PASS



NTNV-n77(3450-3550)-PC2-30-90-M-DFT-QPSK-Inner_1RB_Right-20000-40000-PASS



NTNV-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-0.15-
30-PASS



NTNV-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-30-
1000-PASS



NTNV-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-1000
-3000-PASS



NTNV-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-300
0-6000-PASS



NTNV-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-6000
-20000-PASS



NTNV-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Left-200
00-40000-PASS



NTNV-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-0.0
09-0.15-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-0.
15-30-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-30.
1000-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-10
00-3000-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-60
00-20000-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-BPSK-Inner_1RB_Right-20
000-40000-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-0.0
09-0.15-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-0.15
-30-PASS




NTVN-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-6000-20000-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Left-20000-40000-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-0.09-0.15-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTVN-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-1
000-3000-PASS



NTNV-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-30
00-6000-PASS



NTNV-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-6
000-20000-PASS



NTNV-n77(3450-3550)-PC2-30-90-H-DFT-QPSK-Inner_1RB_Right-20
000-40000-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-0.0
09-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-0.1
5-30-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-30
1000-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-100
0-3000-PASS



NTVN-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-30
00-6000-PASS



NTVN-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-600
0-20000-PASS



NTVN-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Left-20
000-40000-PASS



NTVN-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-0
009-0.15-PASS



NTVN-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-0
.15-30-PASS



NTVN-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-30
-1000-PASS



NTVN-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-1
000-3000-PASS



NTVN-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-30
00-6000-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-6
000-20000-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-BPSK-Inner_1RB_Right-20
000-40000-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-0.
009-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-0.1
5-30-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-30
-1000-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-100
0-3000-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-30
00-6000-PASS




NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-600
0-20000-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Left-2000-40000-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-009-0.15-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-0.15-30-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-30-1000-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-1000-3000-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-3000-6000-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-6000-20000-PASS



NTNV-n77(3450-3550)-PC2-30-100-L-DFT-QPSK-Inner_1RB_Right-20000-40000-PASS

Frequency Stability for SA

Test Result

Voltage											
Band	SCS	Bandwidth	Modulation	Channel	RB Config	Voltage (Vdc)	Temperature (°C)	Deviation (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
n77(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	VL	NT	-9.38	-0.00268	±2.5	PASS
n77(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	VN	NT	-6.94	-0.001983	±2.5	PASS
n77(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	VH	NT	-3.42	-0.000977	±2.5	PASS

Temperature											
Band	SCS	Bandwidth	Modulation	Channel	RB Config	Voltage (Vdc)	Temperature (°C)	Deviation (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
n77(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	-30	-10.09	-0.002883	±2.5	PASS
n77(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	-20	3.63	0.001037	±2.5	PASS
n77(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	-10	-2.9	-0.000829	±2.5	PASS
n77(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	0	-7.67	-0.002191	±2.5	PASS
n77(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	10	-0.94	-0.000269	±2.5	PASS
n77(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	20	-8.3	-0.002371	±2.5	PASS
n77(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	30	-8.55	-0.002443	±2.5	PASS
n77(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	40	0.54	0.000154	±2.5	PASS
n77(3450-3550)	30	100	DFT-QPSK	M	Outer_Full	NV	50	0.44	0.000126	±2.5	PASS

***** End of the Report *****