

MANUAL

JVL RF Remote Controller is designed for “Media Stream” device.

The Remote Control has 3 blue LEDs and 8 buttons on its front panels.

See indication below.



The buttons are separated into the following 6 groups: “POWER”; “MUTE”;“SKIP”; “Volume Up”, “Volume down” and three channel selection buttons: “1”, “2”, “3”.

The Remote Control “POWER” button is only for turning the power on, or off for JVL “Media Stream” device. Press the “POWER” button to turn the power off for “Media Stream” device while in energized condition , instead, press the “POWER” button to turn the power on for the “Media

Stream” device and start to work while in power-off condition.

“Mute” button is for controlling whether the volume of the “Media Stream” device is turned on. The volume of device which is mute is turned on when pressing the “Mute” button, and vice versa.

Press “Skip” button, thus the “Media Stream” device will jump to the next unit.

The button of “Volume Up” and “Volume down” is to controlling the volume size of the “Media Stream” device.

“channel selection buttons” is for selecting the channels.

The remote control will not transmit the command to receiver when multiple buttons are pressed down at the same time.

If no key is pressed, the remote control is in energy-saving state.

FCC NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:1. This device may not cause harmful interference, and 2. This device must accept any interference received, including interference that may cause undesired operation.