

R&R Games Presents
HIDE & SEEK
Safari® junior

Play hide and seek with your animal friends! Your seeker wand tracks the Hide & Seek Junior animal with a signal that only they can hear. When the animal hears it, they'll answer you back! So listen for their sounds and hunt around to be the first to find where the animal is hiding! Wands work with all Hide & Seek Junior animals.

INSTRUCTIONS:

Note – When first removing animal from package, disconnect Try-Me wire by pulling it from the animal and discard it.

- 1- Switch the animal on and hide it. Can be hidden indoors or out.
- 2- Player switches on wand and presses button. Animal will briefly call out. Seek out the animal by listening for its' calls. One player can also control the wand while other players seek for the animal.
- 3- Multiple animals can be hidden. Those in range of Seeker will call out when wand button is pushed.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID of Rx part is shown inside of sound unit of plush, when you open the battery cover of sound uint, it is on the top right corner. FCC ID of Tx part is shown on the bottom of wand.

WARNING: : Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

FCC ID LABLING AND LOCATION

Suggested FCC ID Label

FCC ID:XWVRR720TX

Suggested FCC ID Label Location

