

Figure 1: CNX-WiFi, Front Side



Figure 2: CNX-WiFi, Right Side



Figure 3: CNX-WiFi, Left Side



Figure 4: CNX-WiFi, Rear Side



Figure 5: CNX-WiFi, Top Side



Figure 6: CNX-WiFi, Bottom Side



Figure 7: CNX-WiFi, Internal Board, Side 1



Figure 8: CNX-WiFi, Internal Board, Side 2



Figure 9: CNX-WiFi, Internal 2.4 GHz Antenna Position



Figure 10: CNX-WiFi, Internal 5 GHz Antenna Position



Figure 11: 450 Watt AC Adapter




Figure 12: DFS Radar Test Signal Generator



Figure 13: DFS Test Setup



Figure 14: RE Setup [18GHz - 40GHz]




Figure 15: RE Setup [1GHz - 7GHz]




Figure 16: RE Setup [30MHz - 1GHz]




Figure 17: RE Setup [7GHz - 18GHz]




Figure 18: CEV Setup [Front]




Figure 19: CEV Setup [Rear]