



Photographs of EUT





Antenna Unit Cover opened (overall)



AIM board



installed in (Antenna Unit)





IMU board


installed in (Antenna Unit)





RCM board



installed in (Antenna Unit)





DDM board



installed in (Antenna Unit)





EGR board



installed in (Antenna Unit)





SSM board


installed in (Antenna Unit)





SSM board

installed in (Antenna Unit)



Shielding CAN removed





CNX-BB





Main board


installed in (CNX-BB)





Main board

installed in (CNX-BB)



Shielding CAN removed