


Photographs of EUT





Antenna Unit Cover opened (overall)



AIM board



installed in (Antenna Unit)





IMU board



installed in (Antenna Unit)







RCM board

installed in (Antenna Unit)



DDM board



installed in (Antenna Unit)





EGR board



installed in (Antenna Unit)






IDM board

installed in (Antenna Unit)



IDM board

installed in (Antenna Unit)





Shielding CAN removed



SSM board


installed in (Antenna Unit)





SSM board


installed in (Antenna Unit)



Shielding CAN removed



CNX-Rac





PDM board

installed in (CNX-Rac)





PDM board

installed in (CNX-Rac)





Shielding CAN removed



Power board


installed in (CNX-Rac)





NSB board

installed in (CNX-Rac)





Back plate board

installed in (CNX-Rac)

