

FIGURE 1
ALEX™ READER(M/N: DS-10)
GENERAL APPEARANCE (ALL)



FIGURE 2
ALEX™ READER(M/N: DS-10)
GENERAL APPEARANCE (FRONT VIEW)



FIGURE 3
ALEX™ READER(M/N: DS-10)
GENERAL APPEARANCE (BACK VIEW)



FIGURE 4
ALEX™ READER(M/N: DS-10)
PORTS



FIGURE 5
ALEX™ READER(M/N: DS-10)
CARD SLOT




FIGURE 6
ALEX™ READER(M/N: DS-10)
LABEL



FIGURE 7
ALEX™ READER(M/N: DS-10)
ADAPTER & USB CABLE



FIGURE 8
ALEX™ READER(M/N: DS-10)
LABEL ON ADAPTER



FIGURE 9
ALEX™ READER(M/N: DS-10)
ADAPTER COVER REMOVED




FIGURE 10
ALEX™ READER(M/N: DS-10)
ADAPTER MAIN BOARD (COMPONENT SIDE)




FIGURE 11
ALEX™ READER(M/N: DS-10)
ADAPTER MAIN BOARD (SOLDERED SIDE)




FIGURE 12
ALEX™ READER(M/N: DS-10)
EARPHONE



FIGURE 13
ALEX™ READER(M/N: DS-10)
GENERAL APPEARANCE (FRONT VIEW)



FIGURE 14
ALEX™ READER(M/N: DS-10)
GENERAL APPEARANCE (BACK VIEW)

