

Jabadoo Track speaker TS-001

2. Push the tone on the remote, the speaker will now connect to the PC.
 Note: In case you use more than one Channel on 2 or 3 different transmitters, push until you reach the desired channel!

Tilrådgivning af fjernbetjeningen: tryk først på den ønskede kanal på fjernbetjeningen.
 Bemærk: I tilfælde af der benyttes mere end 1 kanal på 2 eller 3 forskellige sendere trykkes der indtil den ønskede kanal er fundet.



Picture 7 / Billed 7

Jabadoo Track speaker TS-001

4. Connect the wireless transmitter to the music source you want to use with the 3.5mm jack of phone plug (see pic. 9)
 Tildel den trådløse sender til den musik kilde, du ønsker at anvende ved hjælp af 3,5mm Jack eller phone jack.



Picture 4 / Billed 4

Jabadoo Track speaker TS-001

Manual

Jabadoo track speaker TS-001 with 3 Phase and 1 Phase adapter

Bugstævning


Jabadoo bliver højstilet TS-001 med 3 fase og 1 fase adapter



Jabadoo Track speaker TS-001

3. 3 Phase adapter: Choose the Phase on the adaptor you intend to use for the speaker, option 1, 2 or 3 (see pic. 3)
 Note: If one Phase adapter, the speaker is already connected skip this point.
 3 fase adapter: Vælg fase du ønsker at anvende til højttaleren ved hjælp af adapter 1, 2 eller 3 (se Billed 3)
 Bemærk: Anvendes der 1 fase adapter spring dette punkt over

3 fase adapter: Vælg fase du ønsker at anvende til højttaleren ved hjælp af adapter 1, 2 eller 3 (se Billed 3)
 Bemærk: Anvendes der 1 fase adapter spring dette punkt over



Picture 3 / Billed 3

Jabadoo Track speaker TS-001

8. You can fine-tune volume and bass on the different Speakers you have (see pic. 8)
 Du kan nu justere volumen og basen på de forskellige højttalere



Picture 8 / Billed 8

Jabadoo Track speaker TS-001

9. The speaker will remember the last recorded adjustment when turned off.
 Højttaleren huser den sidste indstilling, når den har været slukket.

FCC WARNING STATEMENT
 FCC NOTE:
 THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.
 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Jabadoo Track speaker TS-001

Picture 1 / Billed 1

2. Push the connection on the adaptor at the way, so the speaker is attached (see pic. 2)
 Tryk tilkoblingen på adapteren helt på plads til adapteren er helt fastgjort (se Billed 2)

3 Phase / 3 fase

1 Phase / 1 fase



Picture 2 / Billed 2

Jabadoo Track speaker TS-001

1. Make sure you connect the adaptor to the track the correct way (see pic. 1)
 Note: Connecting the adaptor the wrong way may cause short circuit.
 Vær sikker på at adapteren bliver tilsluttet til skinnen den rigtige vej. Tilslutning af adapteren den forkerte vej kan forårsage kortslutning.

3 Phase adapter / 3 fase adapter



1 Phase adapter / 1 fase adapter



Jabadoo Track speaker TS-001

Jabadoo Denmark
 Mølleengen 19b,
 2000 København
 Denmark
 Mail: info@jabadoo.dk



Hong Kong office:
 Unit 714, 7/F, Metro Ltd.,
 38 Kwai Yee St.,
 Kwai Chung, NT, Hong Kong
 Mail: info@jabadoo.org

Jabadoo Track speaker TS-001

5. Choose the Channel you want to use option 1, 2 or 3 (see pic. 5)
 Vælg den kanal du ønsker at anvende ved hjælp af 1, 2 eller 3 (se Billed 5)



Picture 5 / Billed 5

Jabadoo Track speaker TS-001

6. Turn on the speaker with the "On" button on the remote (see pic. 6)
 Tryk fjernbetjeningens "On" knappen på fjernbetjeningen (se Billed 6)



Picture 6 / Billed 6