


ION ROAD ROCKER

SOUND SYSTEM
BATTERY LEVEL

LOW 1 2 3



FOR MAXIMUM BATTERY LIFE:

- RECHARGE THE BATTERY AFTER EACH USE
- USE AND RECHARGE THE BATTERY AT LEAST ONCE A MONTH
- AVOID COMPLETELY DRAINING THE BATTERY
- DO NOT SERVICE, MODIFY, OR REPLACE THE BATTERY YOURSELF
- IF THE BATTERY FAILS TO CHARGE, CONTACT ION AUDIO: WWW.IONAUDIO.COM

FCC ID: Y4O-PA14B

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

