



User Manual



Your package include following accessories


		
Console	Gun	Launcher
		
User Manual	AV Cable	AC Adaptor

Main Unit Front View




.2.

Main Unit Rear View




Console Batteries Case




.3.

Gun Key Functions



.4.

Console Connected to the TV



- 1 Connect the console with TV via the AV cable with 6 color joint respectively
- 2 Power the console with the AC adaptor.
- 3 Put the launcher on the up or down frame of the TV and connect to the light BAR port, please note that there shouldn't have barrier before the launcher.
- 4 When it inconvenient for use the launcher, ensure the console in the middle place before the TV in order for the veracity of the light gun.
- 5 Put 4*AA batteries on the gun and turn on the switch, the red LED light.
- 6 It would be perfect by stand 1.5 meters away from launcher, angel should be ± 25 degree from the middle of the TV.

.5.

Light gun calibration mode



First



Second




Third

- 1、Aim at the Red area on the upper left, shoot and go to the next frame
- 2、Enter into next frame and aim at the red area ,shoot and go to the next frame
- 3、In the third picture, aim at the point in the middle and shoot, until now, calibration completed, it will enter into the menu section.

Menu selection mode



- 1、It will enter into the menu selection mode after you completed calibration. You can find the game picture on the left screen while on the right will show the game name.
- 2、After you select the game, enter it by aim at the picture and shoot.



1. It will show the “LOADING” on the screen after you selected the game, just wait for a while you can start the exciting game.

.8.



During playing process, Press exit on the gun to quit the game and return back to menu. it will go to select mode for you to choose continue or exit the menu.

.9.

Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.