



**MA-861-F**  
**BLUETOOTH HEADPHONES**  
**INSTRUCTION MANUAL**



bluetooth technology

Please read all instructions carefully and retain for future reference.

## Getting Started

Remove the Bluetooth headphones from the box.  
Remove all packaging from the Bluetooth headphones.  
Place the packaging inside the box and either store or dispose of safely.

## In the Box

Bluetooth Headphones  
USB Charging Cable  
Instruction Manual

## Features

Bluetooth technology lets you stream audio wirelessly.  
Audio controls built directly into the headphones.  
Built-in microphone.

## Safety Instructions

Keep the headphones away from heat sources, direct sunlight, humidity, water and any other liquid.

Do not operate the headphones if they have been exposed to water, moisture or any other liquid to prevent against electric shock and/or injury to yourself and damage to the headphones.

Do not use the headphones if they have been dropped or damaged in any way.

Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.

Do not use the headphones with wet hands.

Do not put objects into any of the openings.

Keep the product free from dust, lint etc.

Do not use this product for anything other than its intended use.

Keep the headphones out of reach of children.

This product is not a toy.


Do not use the headphones at excessive levels as damage to hearing may occur.

Batteries (battery pack or batteries installed) should not be exposed to excessive heat sources, such as fire or sunlight.

Exhausted batteries should be removed from the headphones.

To dispose of the batteries take them to your local battery recycling station. Contact your local government offices for details.

## Description of Parts



## Instructions for Use

### Charging the Battery

The headphones have a built-in rechargeable battery. In order to obtain the best performance from the battery, it is recommended that you fully charge it before using the headphones for the first time. Connect the supplied USB cable to a USB port on a computer and connect the other end to the USB port on the right headphone. This can be found underneath the band, below the decrease volume button.

Whilst charging, the LED indicator light on the right headphone will illuminate red. When the battery is fully charged the LED indicator light goes out.

**Note:** Please only use the supplied USB Cable to charge the headphones. A full charge of the headphones takes approximately 3 hours.

Optimum battery performance is only achieved after a number of charge and discharge cycles. In order to obtain best battery performance, charge and discharge the battery regularly.

If left unused, the battery will lose charge over time. If you have not used the headphones for a while please recharge the battery before use.

### Pairing the Headphones

The Bluetooth headphones can wirelessly stream audio from any Bluetooth device within a 10 metre range.

Ensure that the Bluetooth function is activated on your device. To do this, please refer to the manufacturer's instructions.

Hold the Play/Pause switch in the centre of the right headphone for at least 6 seconds to activate Bluetooth pairing. The LED will flash blue to indicate the headphones have entered pairing mode. Once the headphones are in pairing mode, search the list of available Bluetooth devices on your device. The headphones will appear as IntempoBT in the device list. Select the headphones and if required enter the passcode 0000.

Once paired, the headphones will emit a tone and the LED indicator light will flash blue.

The headphones will remain in pairing mode for several minutes until a device is paired, after which they will leave pairing mode.

### Listening To Music via Bluetooth

Once the headphones are paired with your device you can stream music wirelessly to your device. Volume can be controlled using the increase and decrease buttons on the right headphone and the song can be skipped forwards and backwards through the playlist or album currently selected. If you receive a call, your ringtone will play through the headphones. Press the Play/Pause button to answer the call and again to end the call.

### Troubleshooting

#### **Unable to Pair with Bluetooth Device**

Ensure that your device is Bluetooth compatible and that the Bluetooth function on your device is switched on.

Check that the headphones are within 10 metres (32 feet) of the Bluetooth device and that there are no obstructions between the headphones and the device.

Ensure the headphones are switched on and the battery has been charged.

#### **Low Volume or No Sound**

Ensure that the volume level on your device is set to an audible level. Adjust the volume for listening to music and making and receiving phone calls on the Bluetooth device. Refer to your device's instruction manual for further information.

#### **No Power when the Headphones are Switched On**

Battery power may be low. Please charge the headphones.

- the symbol of Figure 1 with a minimum height of 5 mm; and
- the following wording, or similar:

To prevent possible hearing damage, do not listen at high volume levels for long periods.



Figure 1 – Warning label (IEC 60417-6044)



Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

#### FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - (1) This device may not cause harmful interference.
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

## Battery Disposal

Once the battery loses its charge, it must be removed and disposed of safely. To remove the battery twist the back panel on the left headphone anticlockwise, remove the cover, lift out the battery and cut the connecting wires. To dispose of the batteries take them to your local battery recycling station for disposal. Contact your local government offices for details.

**g) A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.**

## Care and Maintenance

Do not expose the headphones to liquid, moisture or humidity to avoid the product's internal circuit being affected.

Do not use an abrasive cleaning solvent to clean the headphones.

Do not expose the headphones to extremely high or low temperatures as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.

Do not dispose of the headphones in a fire as it will result in an explosion.

Do not expose the headphones to sharp objects as this will cause scratches and damage.

Do not drop the headphones as the internal circuit may become damaged.

Do not attempt to disassemble the headphones as this may cause damage.

## Contact us

DONGGUAN FEIHAO INDUSTRIALIST CO.,LTD

No.8,Fengyi Road,Dakan Village,Huangjiang,DongGuan,China

TEL:0769-89029933

FAX:0769-89029566

## Specification

Bluetooth Specification: Bluetooth V3.0+EDR

**Operating Range: 10 metres**

**Battery: 520 mAh - Lithium Polymer Battery**

Charging Input Voltage: DC5V

Charging Time: About 3 hours