


HOTT

Since 1999


H101 TRUE WIRELESS EARBUDS




MANUAL

Please read this manual carefully before using the headphones


PACKING LIST




Microphone inlet hole
Follow the light indicator




Multi-function button location




Power indicator



Type-C charging port



Manual & warranty card



Type-C power cord

PRODUCT INTRODUCTION

(1)Except for the operation methods specifically marked in the manual,please do not try to disassemble or replace any parts in the earbuds,

(2)Don't put the earbuds in the water or any others liquid,The earbuds are not waterproof, If any liquid enters the product by accidentally, please disconnect and remove the connection immediately,

(4)Please make sure that there is no water on your hands when installing or uninstalling the product to avoid electro shock ,

(5)Do not put the product near by the heat source or expose it to the fire source directly,

(6)Do not put the product in the environment with strong electromagnetic force, otherwise it will cause product malfunction,

Product specification

Bluetooth range; ≥10M

Earbuds battery capacity: 30 mAh

Duration: about 4 hours (headset)

Charging time: about 1 hour (headset)

Rated input: 5V 30mA

Charging box specifications

Battery capacity: 320mAh

Charging time: about 1.5 hours


Rated input: 5V 320mA

(All technical information is subject to actual performance)

Charge the charging box

Connect the charging box to the 5V power adapter with the Type-C charging cable

(Reminder: Open or close the charging box, if the red light breathing effect appears, please timely Charge the charging box.)



Rated input: 5V 30mA(headset) 5V 300mA(charging case)

LED Indicator Status

The headset	Put the headphones in the charging case, Automatically charge the headset	Pairing status: blue light flash Charging state: the blue light is always on Connected status: Lights off Charging completed: Lights off MusicCall Status: Lights off Low Power: Lights off
Charging box	Use the supplied charging cable, Connect power to charge	Charge the charging box, the red light flashes during the charging process of the charging box, The red light is always on after charging The box is full of electricity
Charging box	Normal power Low battery	When the cover is opened or closed, the blue light will light up for about 20 seconds When the cap is opened or closed, the flashing red light will be extinguished for about 25 seconds

Product Operation Instructions

1 Boot

Method 1: Open the cover of the charging box and start the headset automatically,

2 to turn it off

Mode 1: Put the earphone back into the charging box and automatically shut down;

Mode 2: When the device is not connected to the smart device, the earphone will shut down automatically after 3 minutes



3 pairs

Method 1: After the earphone is taken out of the charging box, the left and right earphones will start up and pair automatically,

Two: Open the Bluetooth list of smart devices, search for "H101 " and Connection (support for single ear use),

Pairing status: "Voice prompt: "Du"


Pairing successful: "Voice prompt "Du"




The operation of the touch button

Music Play Mode


Left/Right headset operation



Pause/play : click on any headset




Last song : Long press for about 2 seconds (left earphone)




Next song : Long press for about 2 seconds (right earphone)

Volume set

Left/Right headset operation




Increase volume: double click the multifunction button on the right headset




To reduce volume: double click the multifunction button on the left headset

Call mode


Left/Right headset operation



Answer an incoming call: Click on any headset




End the call: click on any headset




Rejected call: press either earphone for about 2 seconds

Voice assistant

In addition to the call state, about three press the headphone touch button to activate the voice assistant function(Support of connected smart devices is required)



Turn on voice assistant: three clicks (left and right headphones)



Turn off the voice assistant three swipes (left and right headphones)

THE NAME AND CONTENT OF HARMFUL SUBSTANCES IN THE EARBUDS

Names	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
PCBA components	○	○	○	○	○	○
Structural components	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364,
○ Indicates that the content of the hazardous substance in all homogeneous materials of the part is in below the limit required by GB/T 26572;
X Indicates that the hazardous substance is found in a certain homogeneous material of the part exceeds The limit requirements specified in GB/T 26572.
This part marked with "X" on the form are all harmful due to the limitations of global technological development, Substitution of substances.

Printed circuit board components:
Including printed circuit boards and their parts, electronic components, etc., and depending on the product model, the earbuds you purchased may not contain all the above components.

10

Electronic and electrical products sold in the People's Republic of China must mark this logo. The number in the logo represents the product under normal use Environmental protection use period.

WARRANTY STATEMENT

Disclaimer

This user manual does not have any form of guarantee,position expression or other implication, The mentioned products,specifications and information are for reference only,and the content will also be updated on the web at any time without additional separate notice

Warranty statement:

The product attached to this document is guaranteed as follows:If the product is twelve (12) months from the date of purchase("Warranty Period"),under normal conditions of use due to quality defects damaged,can be repaired,Free repair,Free replacement if the manufacturer confirms that it cannot be repaired; repaired or replaced product,Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days),Purchased by sale the latest date shall prevail;If the purchase date cannot be determined,the warranty period shall be 13 (13) Monthsly calculation,

If you apply for a warranty,please call the product service hotline first and execute it in the manner instructed by us,When applying for warranty,you need to provide an accurate,complete and clearly filled out valid sales invoice,The above guarantee does not apply to the following situations:
1. Exceeding the validity period of the three packs;
2. Altering the warranty card and product code does not match the product body;
3. Causes caused by misuse,abuse or improper transportation,use,maintenance or storage obstacles or damage;
4. Failure or damage caused by force majeure (such as earthquake,war,dissaster,etc.) or accident bad;
5.The zipper and lower buckle are damaged due to excessive force;
6,Disconnection or tearing caused by excessive load;

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: Y82-4101

Because the earbus is too small, the FCC ID number can only be printed on the charging box.01

WARRANTY STATEMENT

1.Any damage caused by third objects;
2.Products with signs of burning or flooding;
3.Damage caused by unauthorized disassembly;
4.Aging,discoloration,abrasion,rapture and other losses that occur during the normal use of the product.

Warranty statement

11.If the original identification label of the product is changed or damaged,this guarantee will become invalid.
The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee,You should check on the spot and raise objections to any discrepancies.

Contact Us

HONGFUTAI E-TECH(SHENZHEN)CO.,LIMITED

Hot:Shut and on

ADD:RF, No.17, Xinxing Industrial Park, Xinxhe Community, Futai Street, Baoan District, Shenzhen 518103, China.

U.S.A Service Center

Tel-Free: 1-866-468-6280(09:00-17:30)

E-mail: service@hott.net.cn

HOTT Copy Customer Service: LCHF-HOTT 13620 Benson Ave, Ste B China, CA 91710-5201.

Germany Service Center

Tel-Free: +49 7171 6707105(8:00-17:00)

E-mail: info.eu@hott.net.cn

Address: Rolf-Michael Pohl Klarenbergstraße 36 73525 Schwilbsch Gm ü nd.