

User manual

Thank you for having present product. This powerful tool will help you make a perfect speech in front of others. It's light, handy, and elegant, which can be your best partner when making presentation. Before using it, we strongly advise you carefully to read the following information and usage.

It consists of two parts: transmitter and USB receiver.

Installation and Usage:

1. Plug the Receiver into the USB port on your PC. Then the system will automatically search for the new hardware and complete the install.
2. Begin your presentation.

Safety precautions:

1. Since RF signal can be interference to other appliance, please keep a distance with RF device when you use it .
2. Do not use this device to aim on human .
3. Caution: Use of controls, adjustments, or performance of procedures other than those specified
4. The device is not a toy, and please keeps it out of the reach from children.

Technical Specifications:

Working Voltage	+1.9V~+5V
Working Current	Transmitter: 8mA; Receiver: 12mA
Frequency Range	2400 ~ 2483MHz*
Modulation Type	FSK.
Rate	1Mbps
Channel	8
Channel Separation	10MHz
Frequency Stability	±156KHz
Transmitter Output Power	0dBm
Receiving Sensitivity	-80dBm (@1Mbps) ; -90dBm (@250kbps)
Working Temp.	-10~+55 °C
Storage Tem.	-30~+85 °C
Storage Tem.	-30~+85 °C