



**Band4-5MHz-QPSK-19975-1RB#0-PASS**      **Band4-5MHz-16QAM-19975-1RB#0-PASS**



**Band4-5MHz-QPSK-19975-25RB#0-PASS**      **Band4-5MHz-16QAM-19975-25RB#0-PASS**



**Band4-5MHz-QPSK-20175-1RB#0-PASS**      **Band4-5MHz-16QAM-20175-1RB#0-PASS**

