





11.4 Setup Photographs:

12.4 Setup Photographs:


Transmit Mode 30-1000 MHz




Transmit Mode 30-1000 MHz




Transmit Mode 1-4 GHz




Transmit Mode 1-4 GHz




Transmit Mode 4-18 GHz



Transmit Mode 4-18 GHz



Transmit Mode 18-20 GHz




Transmit Mode 18-20 GHz

13.4 Setup Photographs:


Receive Mode, 30-1000 MHz



Receive Mode, 30-1000 MHz




Receive Mode, 1-10 GHz



Receive Mode, 1-10 GHz

14.4 Setup Photographs:


Idle Mode



Idle Mode




Transmit Mode



Transmit Mode

17.4 Setup Photographs:

21.4 Setup Photographs:

25.4 Setup Photographs: