




## Battery Changing Instruction



1. Open the battery compartment lid



2. Placing two AAA batteries according to the direction instruction in the compartment



3. Close the lid to ensure batteries not falling out  
Regularly, a new and full charged battery is good for use for 3 months

## Installation

Take out the USB Dongle from the package Put the Dongle into the USB port in the computer which is going to use this keyboard as show below



Please wait for 1min 20.5sec for the first time pairing, and about 5.5 second after first time use for the keyboard and dongle doing paring, and then start to use. Available distance is 3M

\*Please make sure that the computer is turned on, workable battery is installed in the keyboard before using. Attention: If keyboard is unable to work at first time of paring, please pull off the dongle and try another USB port in the computer

## Icon and Functionality

	Homepage
	E-mail
	My Favorite
	My Computer
	Calculator
	Media Player

### CAUTION:

Modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try correct interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Caution :** To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two Conditions:  
(1) this device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.

**FCC ID: YKZ-MK305**