







802.11ax20 / 6855 MHz / Chain A




802.11ax20 / 6855 MHz / Chain B




802.11ax20 / 6855 MHz / Chain C




802.11ax20 / 6855 MHz / Chain D




802.11ax20 / 6875 MHz / Chain A




802.11ax20 / 6875 MHz / Chain B




802.11ax20 / 6875 MHz / Chain C




802.11ax20 / 6875 MHz / Chain D




802.11ax20 / 6895 MHz / Chain A




802.11ax20 / 6895 MHz / Chain B




802.11ax20 / 6895 MHz / Chain C




802.11ax20 / 6895 MHz / Chain D




802.11ax20 / 7015 MHz / Chain A




802.11ax20 / 7015 MHz / Chain B




802.11ax20 / 7015 MHz / Chain C




802.11ax20 / 7015 MHz / Chain D




802.11ax20 / 7095 MHz / Chain A




802.11ax20 / 7095 MHz / Chain B




802.11ax20 / 7095 MHz / Chain C




802.11ax20 / 7095 MHz / Chain D




802.11ax40 / 5965 MHz / Chain A




802.11ax40 / 5965 MHz / Chain B




802.11ax40 / 5965 MHz / Chain C




802.11ax40 / 5965 MHz / Chain D




802.11ax40 / 6205 MHz / Chain A




802.11ax40 / 6205 MHz / Chain B




802.11ax40 / 6205 MHz / Chain C



802.11ax40 / 6205 MHz / Chain D



802.11ax40 / 6405 MHz / Chain A



802.11ax40 / 6405 MHz / Chain B