








802.11ax40 / 6405 MHz / Chain C




802.11ax40 / 6405 MHz / Chain D



802.11ax40 / 6445 MHz / Chain A




802.11ax40 / 6445 MHz / Chain B




802.11ax40 / 6445 MHz / Chain C


802.11ax40 / 6445 MHz / Chain D




802.11ax40 / 6485 MHz / Chain A




802.11ax40 / 6485 MHz / Chain B




802.11ax40 / 6485 MHz / Chain C




802.11ax40 / 6485 MHz / Chain D




802.11ax40 / 6525 MHz / Chain A




802.11ax40 / 6525 MHz / Chain B




802.11ax40 / 6525 MHz / Chain C




802.11ax40 / 6565 MHz / Chain A




802.11ax40 / 6565 MHz / Chain C




802.11ax40 / 6525 MHz / Chain D




802.11ax40 / 6565 MHz / Chain B




802.11ax40 / 6565 MHz / Chain D




802.11ax40 / 6725 MHz / Chain A




802.11ax40 / 6725 MHz / Chain B




802.11ax40 / 6725 MHz / Chain C




802.11ax40 / 6725 MHz / Chain D




802.11ax40 / 6845 MHz / Chain A




802.11ax40 / 6845 MHz / Chain B




802.11ax40 / 6845 MHz / Chain C




802.11ax40 / 6885 MHz / Chain A




802.11ax40 / 6885 MHz / Chain C



802.11ax40 / 6845 MHz / Chain D



802.11ax40 / 6885 MHz / Chain B



802.11ax40 / 6885 MHz / Chain D