







802.11ax40 / 6925 MHz / Chain A




802.11ax40 / 6925 MHz / Chain B




802.11ax40 / 6925 MHz / Chain C




802.11ax40 / 6925 MHz / Chain D




802.11ax40 / 7005 MHz / Chain A




802.11ax40 / 7005 MHz / Chain B




802.11ax40 / 7005 MHz / Chain C




802.11ax40 / 7085 MHz / Chain A




802.11ax40 / 7085 MHz / Chain C




802.11ax40 / 7005 MHz / Chain D




802.11ax40 / 7085 MHz / Chain B




802.11ax40 / 7085 MHz / Chain D




802.11ax80 / 5985 MHz / Chain A




802.11ax80 / 5985 MHz / Chain B




802.11ax80 / 5985 MHz / Chain C




802.11ax80 / 5985 MHz / Chain D




802.11ax80 / 6225 MHz / Chain A




802.11ax80 / 6225 MHz / Chain B




802.11ax80 / 6225 MHz / Chain C




802.11ax80 / 6225 MHz / Chain D




802.11ax80 / 6385 MHz / Chain A




802.11ax80 / 6385 MHz / Chain B




802.11ax80 / 6385 MHz / Chain C




802.11ax80 / 6385 MHz / Chain D




802.11ax80 / 6465 MHz / Chain A




802.11ax80 / 6465 MHz / Chain B




802.11ax80 / 6465 MHz / Chain C



802.11ax80 / 6465 MHz / Chain D



802.11ax80 / 6545 MHz / Chain A



802.11ax80 / 6545 MHz / Chain B