








802.11ax80 / 6545 MHz / Chain C




802.11ax80 / 6545 MHz / Chain D



802.11ax80 / 6625 MHz / Chain A




802.11ax80 / 6625 MHz / Chain B




802.11ax80 / 6625 MHz / Chain C


802.11ax80 / 6625 MHz / Chain D




802.11ax80 / 6705 MHz / Chain A




802.11ax80 / 6705 MHz / Chain B




802.11ax80 / 6705 MHz / Chain C




802.11ax80 / 6705 MHz / Chain D




802.11ax80 / 6785 MHz / Chain A




802.11ax80 / 6785 MHz / Chain B




802.11ax80 / 6785 MHz / Chain C




802.11ax80 / 6785 MHz / Chain D




802.11ax80 / 6865 MHz / Chain A




802.11ax80 / 6865 MHz / Chain B




802.11ax80 / 6865 MHz / Chain C




802.11ax80 / 6865 MHz / Chain D




802.11ax80 / 6945 MHz / Chain A




802.11ax80 / 6945 MHz / Chain B




802.11ax80 / 6945 MHz / Chain C




802.11ax80 / 6945 MHz / Chain D




802.11ax80 / 7025 MHz / Chain A




802.11ax80 / 7025 MHz / Chain B




802.11ax80 / 7025 MHz / Chain C




802.11ax80 / 7025 MHz / Chain D




802.11ax160 / 6025 MHz / Chain A



802.11ax160 / 6025 MHz / Chain B



802.11ax160 / 6025 MHz / Chain C



802.11ax160 / 6025 MHz / Chain D