


TRANSMITTER

ANTENNA

high / low
gain switch

To adjust for
the different
television
audio out
values



optical

coax

left

analog

right

power

TRANSMITTER (BOTTOM VIEW)

