




Photograph 2. Bottom Board (Flash Card Removed)




Photograph 3. Bottom Board




Photograph 4. Cover Off




Photograph 5. Radio Card (Shield Removed)



Photograph 6. Radio Card Bottom



Photograph 7. Radio Card Top



Photograph 8. Top Board



Photograph 9. Flash Card Bottom



Photograph 10. Flash Card Top