

4.2.5 Test Setup Configuration

The following photographs show the testing configurations used.



Charging Mode



Battery Mode

