

Chapter 8: Multimedia Applications

8.1 Photos and Videos


This device is equipped with rear and front cameras to take photos and videos. By default, your device uses the rear camera to take photos or record videos.

Taking a photo



1. From the Home screen, tap **Apps** > **Camera**.
To switch to front camera, tap .
2. Aim the device at the subject.
Tap  to zoom in/out on the subject.
3. Tap  to take the shot.
To focus on the image before taking the shot, tap and hold . The focus frame turns green to indicate that the focus is set.

Recording a video



1. From the Home screen, tap Apps > Camera.
2. Tap to switch to Camcorder mode.
To switch to front camera, tap .
3. Aim the device at the subject.
4. To start recording, tap .
To stop recording, tap .

Reviewing a photo

After taking a photo, tap the window located at bottom left corner to preview the latest captured photo on the screen.


- Tap to start the slideshow.
- Tap to share the photo via Twidroyd, Picasa, Bluetooth, Gmail, or Email.
- Tap to delete the photo. Then, tap **Confirm Delete** to confirm file deletion.
- Tap to view photo details, rotate the photo to the left/right, set the photo as contact photo/wallpaper, or crop the photo.
- Tap to return to Camera mode.



Reviewing a video

After recording a video, tap the window located at bottom left corner to preview the latest recorded video on the screen.

- Tap  to play the video.
- Tap  to start the slideshow.
- Tap  to share the video via Twidroyd, YouTube, Bluetooth, Gmail, or Email.
- Tap  to delete the video. Then, tap **Confirm Delete** to confirm file deletion.
- Tap  to view the video details.
- Tap  to return to Camcorder mode.



Configuring camera settings

Tap the icon (on the right side of the screen) to access the respective camera/camcorder menu. Swipe your finger up and down to scroll the page for more options.



Tap to view and adjust the general settings of your camera:

Mode	Setting	Available options
	Flash mode	Auto, On, Off
	White balance	Auto, Incandescent, Daylight, Fluorescent, Cloudy
	Color effect	None, Mono, Sepia, Negative, Solarize
	Scene mode	Auto, Portrait, Landscape, Night, Theatre, Beach, Snow, Sunset, Fireworks, Candlelight, Sports
Camera mode	Store location	Off, On
	Focus mode	Auto, Infinity, Macro
	Exposure	-2, -1, 0, +1, +2
	Picture size	5M Pixels, 3M Pixels, 2M Pixels, 1M Pixels, VGA
	Picture quality	Super fine, Fine, Normal
	Restore default	OK, Cancel
	Flash mode	On, Off
	White balance	Auto, Incandescent, Daylight, Fluorescent, Cloudy
Video mode	Color effect	None, Mono, Sepia, Negative, Solarize
	Video quality	High, Low, YouTube (High, 15m)
	Time lapse interval	Off, 1s, 1.5s, 2s, 2.5s, 3s, 5s, 10s

8.2 Viewing Photos & Videos

Viewing photos

1. From the Home screen, tap  Apps > **Gallery**.
2. Tap the desired folder to view the images in thumbnails.
3. Tap an image to view.



4. Swipe your finger to the left/right to view the previous/next image.
 - To play the slideshow, tap .
 - To share the photo via Twidroyd, Picasa, Bluetooth, Gmail, or Email, tap .
 - To delete the photo, tap . Then, tap **Confirm Delete** to confirm file deletion.
 - To edit the photo, tap  to show more options.



Playing videos

1. From the Home screen, tap **Apps** > **Gallery**.
2. Tap the desired folder to view the videos in thumbnails.
3. Tap the video to playback.




8.3 Using Music Player


You can transfer music to the device from the computer. From the Home screen, tap **Apps** > **Music**.

Music screen


- **Playback screen:** Displays the playback area with the playback controls.



- **Library screen:** Displays folder categories to search for media files. It contains the following categories: **New and recent**, **Albums**, **Artists**, **Songs**, **Playlists**, and **Genres**.




- **New and recent screen:** Displays the current playlist



Playing music

To play music

1. From the Home screen, tap **Apps** > **Music**.
2. Tap **Songs** to view the list of songs.
3. Tap a song to play.




Managing playlists

To add a music file to playlist

Add songs to a specific playlist or create a playlist.

1. From the Home screen, tap **Apps** > **Music**.
2. Browse for the song that you want to add in a playlist.
3. Select the song and tap **More** > **Add to playlist**.
4. Select from the current playlist or tap **New playlist** to create a new playlist. The song is added to the playlist.


NOTE: If you create a new playlist, enter the playlist name, then tap **OK**.



To remove a music file from playlist

1. From the Home screen, tap  > **Music**.
2. Tap **Playlists** and browse for the playlist.
3. Select the song and tap  > **Remove from playlist**.

The song is removed from the playlist.



8.4 Sharing Media


Once your device has an active network connection, you can share media content on your device to other shared computers or NAS devices located on the same network as your device.

Viewing media files

You can view the media content stored on other shared computers or NAS device located on the same network.

1. From the Home screen, tap  > **Myriad UPnP Remote**.
2. On the top of the screen, select the appropriate media player type.
 - To play videos, select **My Video Player**.
 - To play music, select **My Music Player**.
 - To view photos, select **My Slideshow**.
3. Tap the desired media server from the server list.
4. Browse the media files on the available folders.
5. Tap the desired file(s) to play.

A green tick icon appears on the selected file.
6. Slide  up, and tap  to play/view the selected file(s).
 - To add the selected file(s) into the playlist, tap .



Downloading media files


You can download the media content stored on other media server to your device.

1. From the Home screen, tap  > **Myriad UPnP Server**.
2. Tap the desired media server from the server list.
3. Browse the media files on the available folders.
4. Tap the desired file(s) to download.
A green tick icon appears on the selected file.
5. Slide  up, and tap  to download the selected file(s).
All files are saved in the memory card.

Sharing media files

You can share the media content stored on your device to other media servers located on the same network.


1. From the Home screen, tap  > **Myriad UPnP Server**.
2. Tap the item that you want to share.
3. To change the server name, tap **My server name**. Enter the server name and tap **OK**.
4. After all settings are completed, tap **Allow media sharing** check box to activate the Media Share function.
5. To view the media files, see “Viewing media files” on page 49.



Uploading media files

You can upload the media content stored on your device to other media servers.

1. From the Home screen, tap  Apps > **Myriad UPnP Server**.
2. Tap **Allow media sharing** check box to activate the Media Share function.
3. Tap  to exit and tap **Myriad UPnP Remote**.
4. Tap your device media server.
5. Browse the media files on the available folders.
6. Tap the desired file(s) to upload.
A green tick icon appears on the selected file.
7. Slide  up, and tap  to upload the selected file(s).



NOTE: When switching from one Wi-Fi network to another, it is recommended to restart **Myriad UPnP Remote** application and tap  > **Kill all UPnP activities** check box to reset all media sharing activities.

Chapter 9: Applications

Your device comes with the following pre-installed applications.

Application	Description
	Browser Browse the web and download files from the Internet. See page 25.
	Calculator Perform basic arithmetic functions, such as addition, subtraction, multiplication, and division. See page 54.
	Calendar Create and track schedule or appointments. See page 54.
	Camera Capture photos and record videos. See page 41.
	Clock Set up alarms. See page 66.
	Contacts Store names, numbers, email, and other information. See page 15.
	Documents To Go View Microsoft® Office and Adobe file formats. See page 55.
	Downloads View or delete the files that you have downloaded in Browser, Gmail, or Email. See page 56.
	Email Send and receive email messages. See page 21.
	File Browser Manage audio, video, photo, and other files. See page 56.
	FM Radio Tune and listen to the radio. See page 57.
	Gallery View and edit photos and videos. See page 45.
	Gmail Access your Gmail account on your device. See page 27.
	Google Search Search applications and contacts on your device, and the Internet using Google Search. See page 37.
	Latitude See your friends' locations and share yours with them. You need to sign in with your Google account to use this feature. See page 35.

Application	Description
	Maps View the map and get directions to your destination. See page 32.
	Market Purchase games and other applications from Android Market and download them to your device. See page 36.
	Movie Studio Create or edit movies on your device. See page 39.
	Music Play and manage music and audio files on your device. See page 46.
	Myriad UPnP Remote Use to view the media content stored on other media server or NAS storage on the same network. See page 49.
	Myriad UPnP Server Use to share your device media content with other computers on the same network. See page 50.
	Navigation Use to track your location, find places, and get driving directions to your destination. See page 33.
	Places Help you to find the places around you. Local information available includes restaurants, coffee shops, bars, hotels, attractions, ATMs, gas stations, and more. See page 37.
	Settings Configure wireless settings and other general settings of your device. See page 62.
	Talk Log in and chat with friends using Google Talk. See page 30.
	TouchPal keyboard Configure the keyboard settings. See page 19.
	Twidroyd PRO Log in and use Twidroyd applications on your device. See page 60.
	Voice Search Use Google Search by saying the word instead of typing them. See page 38.
	YouTube Watch videos from YouTube on your device. See page 38.

9.1 Browser

Open the **Browser** to view web pages. See “Browsing Web Pages” on page 25.

9.2 Calculator

With **Calculator**, you can perform basic arithmetic functions on your device.

1. From the Home screen, tap  **Apps** > **Calculator**.
2. Use the on-screen calculator keypads to perform arithmetic calculation.




9.3 Calendar

The **Calendar** lets you schedule and sound alarms for appointments, meetings and other events. Scheduled appointments for the day can be displayed on the Home screen.

To schedule an event

1. From the Home screen, tap  **Apps** > **Calendar**.
2. Tap  > **New event**.
3. Enter the event details.
4. Select the date and time for **From** and **To** fields.
NOTE: For an all-day event, check **All day**.
5. To set repetition, select the repetition from the list.
6. To set a reminder, select the time from the list.
7. When finished, tap  **Done**.

TIP: From the Calendar screen, tap and hold a day or a time slot then set a new appointment on the tapped date or time.



9.4 Camera

Capture photos and record videos with this device. See “Photos and Videos” on page 41.

9.5 Clock

Set alarms with this device. See “Alarms settings” on page 66.

9.6 Contacts


View or manage your contact list. See “Contacts” on page 15.

9.7 Documents To Go

Documents To Go allows you to open Microsoft® Office and Adobe file formats.

1. From the Home screen, tap  Apps > **Documents To Go**.
2. Tap the document category that you want to view.
3. Tap the file you want to open.
 - Swipe your finger on the screen to pan or go through other pages.
4. To close the file, tap .

NOTE: To create a new document or edit an existing document, purchase the full version of **Documents To Go**.



Purchase Documents To Go

To get the full version of Documents To Go:

1. Tap **Upgrade Store**.
2. Tap **More**. Browser is launched and you will be redirected to www.dataviz.com.
3. Follow the on-screen instructions to complete purchase.