User Manual

1.Precautions

Before using the phone, please read the following instructions and follow them to avoid danger or violating the law. This manual contains detailed safety information.

Traffic safety

Don't use your phone while driving; if necessary, park your car first.

Switching off the phone in gas station

At gas station or a place close to inflammables and chemicals, don't use your phone.

Switching off the phone while traveling by air

While traveling by air, it is a must to switch off your phone; otherwise, you violate the law.

Switching off the phone in hospital

Please abide by relevant rules and regulations, don't use your phone at the place which is in close proximity to medical devices (such as pacemaker and hearing aids).

Interference

Voice quality of all cellular phones will be influenced by radio interference.

Using the phone properly

Hold the phone close to your ear; don't touch the antenna unnecessarily.

Professional service

Only qualified service man can install or repair the phone.

Connecting to other device

Before connecting the phone to other device, please read user manual of the device to acquire detailed safety instructions; don't connect the phone to any unmatched product.

Accessory

Use the specified battery and accessories only; otherwise, the phone may be damaged.

2 Before Using Your Phone

2.1 Fitting SIM card

! ·Please keep SIM card away from children.
·Any scratch or bending of SIM card may
  damage SIM card easily; Therefore, pay
  special attention while inserting, removing
  or storing SIM card.

  ·Before removing SIM card, be sure power
is off and remove the battery.
Turn the phone to back side; unlock the latch
and insert the SIM card into SIM card retainer,
then lock the latch (as shown by the arrow).
While fitting the SIM card, be sure that metal
contact clip of SIM card is downward and the
corner clip is at lower right corner (as shown in
the figure).

2.2 Fitting the battery

Put the battery at the back of phone, put the
battery toward the bottom of the phone, insert
the back cover and lock it in position (as
shown by the arrow).

2.3 Removing the battery

Turn the phone to back side, pull down the
release latch to remove the back cover, lift up
the battery and remove it from the phone. All
settings or data saved in SIM card and the
phone may be lost after you remove the
battery.

2.4 Charging the battery

Attach battery charger plug marked with an
arrow to the charging slot at the bottom of the
phone.
After the connection of battery charger, the
grid of battery level icon scrolls on the top right
corner of the display. When the grid stops
scrolling and battery indicator shows full grid,
the battery is fully charged; press the button
on the two sides of charges to remove the
plug.

! ·When the battery is in low capacity, alarm
  information appears on internal display
  and the indicator shows no power. The
  phone will turn off automatically when the

power is extremely low. Don't keep the battery in low capacity for long time; otherwise, it will damage the battery and shorten its service life.

·Please use the specified battery charger to ensure that the phone works normally.

2.5 PIN

PIN

The PIN (Personal Identification Number) protects your SIM card against unauthorized use. Generally PIN is provided with SIM by network operator.

If you input incorrect PIN for three consecutive times, the SIM card will be locked; input PUK code to unlock it; please contact network operator for details.

PIN2

The PIN2 is also provided with SIM card by network operator because it is required to input the PIN2 to use some function (unit of accounting, fixed dialing number).

If you input incorrect PIN2 for three consecutive times, the phone will be locked; it is required to input PUK2 code to unlock the phone; please contact network operator for details.

PUK code

To unlock SIM card, PUK code is required; Generally PUK code is provided with SIM card; otherwise, you should contact service provider to acquire PUK code; if you lose this PUK code, please contact service provider.

3 . Basic Function Description

3.1 Turning the phone on

1. Long press red button to turn your phone on; then backlight is on and instant animation appears.

If SIM card is not installed or in poor contact; alarm prompt appears; press red button to turn off your phone, and re-install SIM card.

! In case SIM card is not installed or in poor contact, your phone will not enter menu mode, only emergency call is available.

2. In case SIM card is being protected by PIN, the prompt—"Input PIN" appears; please input correct PIN and press left soft button to confirm.

3. In case that SIM card is locked, the prompt—input PUK code, will appear.

4. The phone will search network automatically after you turn it on.

! When the phone has searched the authorized network, network name and signal strength will appear on the display; in case the phone fails to search the authorized network, only emergency call or other non-communication function is available.

3.2 Inquiring IMEI (International Mobile Equipment Identity)

In standby mode, input "#*06#" and press green button or left soft button to confirm and inquire IMEI.

3.3 Making a call

In standby mode, use the numeric keys to enter the number, including necessary area code; press right soft button to cancel wrong input; after input, press green button to make the call.

Press left soft button to confirm and enter menu option. Press upward/downward navigation button to select an option and perform function.

·Sending message

Edit short message/MMS (Multimedia Messaging Service) message and send it to the inputted phone number.

·Add to phone memory

Add the inputted phone number to phone memory.

·Calling

Call the number.

3.4 Reject incoming call

Press red button or fold your phone to reject incoming call; when your phone flip is closed,

long press up/down side button to reject the incoming call.

3.5   Answering a call
When an incoming call arrives, you will be prompted in the following ways (vibrating, ringing, ect.); if the network supports caller ID function, the name or phone number of the caller will be shown on the display; you may answer the call in the following ways:
When the phone flip is closed, slide the flip upwards to answer (To activate this feature, set the menu-> answer option-> slide the flip upwards to answer, set "ON").
When the phone flip is closed, press green button or left soft button to answer the call.

3.6   Adjusting volume
In standby mode, short press up/down button on the left side of your phone, adjust voice volume (corresponding picture appears); adjust earpiece volume during a call by pressing up/down button on the left side of your phone.

3.7   Ending a call
Press red button or slide the flip downwards to end a call; press red button or slide the flip downwards to cancel a call your dialed.

3.8   Emergency service
You can directly dial emergency service number without SIM card.
The emergency service number varies from different networks; please contact network operator for details.

3.9   Making international call
To make an international call, first long press button "?" of numeric key to display "+" ("+" is a code for making international call); then enter country code, area code and phone number; press green button to make the call.

3.10   Extension number dialing
After entering phone number, please long press button "*" till letter "P" appears on the display to input your extension number.

3.11 Missed /Answered/Dialed calls
You can view number, relevant time and date of your recent missed/answered/dialed call in the following three ways:

· If you miss an incoming call, "calls unanswered" and the quantity of such calls appear on the display; press left soft button to display unanswered call list and press upward/downward navigation button to view it.

· In standby mode, press green button to display recent calls; press left soft button to enter the interface switching between recent dialed calls, missed calls and answered calls via pressing left/right navigation button; then corresponding prompt appears on the display, press upward/downward navigation button to select the call list (listed by the order of calling time).

· In standby mode, press left soft button to enter main function menu and select "Call List"; you may select sub-menu of miss calls, answered calls and dialed calls; press upward/downward navigation button to look into the number you need.

3.12 Call forwarding
If the function of call forwarding is enabled, you can set forwarding condition (such as call forwarding unconditional, call forwarding if busy, call forwarding if no answer, call forwarding if unreachable); or the incoming call is forwarded to voice mailbox or other phone number.

3.13 Call waiting
Once Call Waiting function is enabled, if an incoming call arrives while you talk over another call, call waiting information will be shown on the display; please subscribe to network operator for this function. You may select the following options:
When you are talking over a call, another incoming call arrives, the following options to

8

handle the incoming call appear on the display (call waiting function is enabled):

·Answer

Hold on ongoing call and answer the incoming call.

·Busy

Reject the incoming call.

·Answer the incoming call after ending the ongoing call,

End the ongoing call and answer the incoming call.

3.14 Call restriction

When call restriction function is enabled, call restriction will be performed according to the preset conditions (call out all, all incoming calls, incoming call while roaming, call out while roaming, call out while international roaming).

3.15 Hold on call

During a call, press left soft button to confirm and enter option menu; press upward/downward navigation button to perform.

·Switch

·Phonebook

Press left soft button to enter phonebook menu; please refer to <u>Phonebook</u> for operation details.

·Message

Press left soft button to enter message menu; please refer to <u>Message</u> for operation details.

3.16 Switching off your phone

In standby mode, long press red button to turn your phone off.

4. Accessories

You may buy the following accessories of our company to work with your phone. Please contact the distributor for details of other accessories.

Supplementary battery

You may buy our lithium battery with different capacities.

Travel charger

Fast charger with extra light weight. The battery will be fully charged quickly. Plug one end of the charger into power socket and connect the other end to accessory interface at the bottom of the phone.

You may check charging status via the display; in case of charging in power-off mode, the phone will not turn on automatically; during charging, you may press button on to turn on your phone.

5. Care & Maintenance

Battery care and maintenance

· The chargeable battery provides power for the phone; when the power is low, please charge the battery; to ensure a longer service life of the battery, it would be better to use up the power before charging.

· When the charger is not in use, please disconnect it from power source; don't connect charger to battery for over one week because overcharging will shorten the service life of the battery.

· Temperature may influence charging; therefore, cool or warm the battery for a while before charging; if the temperature of the battery is over 40ºC, it is impossible to charge the battery.

· Apply the battery to original use to avoid short circuit. When conductive material directly connects to the positive and negative poles of the battery, it will cause short circuit.

· Don't use damaged battery.

· Exposing battery to extreme cold or hot place will shorten the service time of the battery and lead to abnormal performance of your phone even if the battery is fully charged.

· Don't put the battery in fire! Please dispose the useless battery in accordance with local rules and regulations.

Phone care and maintenance
Please follow the instructions below:
· Keep phone and all accessories away from children.
· Keep the phone dry because liquid may erode circuit board.
· Keep the phone far away from high temperature because high temperature may shorten the service time of electronic device, melt plastic and damage battery.
· Don't remove the shell of the phone or disassemble the phone because unprofessional disassembling may damage the phone.
· Don't clean your phone with strong detergents.
· Only use accessories provided with the phone; or, it will make the warranty invalid.

6. Security Information
You must follow safety regulations for protecting user and environment while using your phone.
Security of transportation
· Except in emergency, if no hand-free device is installed, don't use your phone while driving; if necessary, park your car at a safe place first. Please abide by relevant laws and regulations.
· If there are no sufficient protective measures, some electronic systems of your car may be influenced by radio wave discharged by your phone.
· It is suggested to use your phone only in car equipped with external antenna.
· Only qualified technician can install your phone in your car.
Security of airplane
Please turn off your phone when aboard airplane because the phone may influence airplane operation and the whole cellular network. It is illegal to use phone in airplane. Failure to observe this instruction may lead to

legal action or denial of GSM services to the offender.

Security of environment

· keep this mind to abide by prevailing relevant rules and regulation; turn off your phone in place where the use of phone is prohibited or when the use of phone may cause interference or danger.

· Using any wireless transmission device including cellular phone may induce interference to medical equipment not protected properly; if you have any question concerning this, please consult doctor or medical equipment manufacturer.

· Your mobile phone may induce interference to medical electronic device such as pacemaker and hearing aids. Please follow the instructions put forward by doctor or medical equipment manufacturer.

· It is suggested to turn off your phone when in vicinity of gas stations, chemical plants or other explosives.

· Observe regulations on use limitation of wireless equipment.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference,
and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the

equipment off and on, the user is encouraged to try to correct the
interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that
to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Information and Statement
The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: 7310 (FCC ID: **Z87AIRUS7310**) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.69W/kg and when properly worn on the body is 0.53W/kg. This device was tested for typical body-worn operations with the back of the handset kept 1.5cm from the body.

To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly.

The use of accessories that do not satisfy these requirements may not
comply with FCC RF exposure requirements, and should be avoided