


# EDIFIER

**R19BT**

**Multimedia Speaker**

## ■ What's in the box



Passive speaker



Active speaker



3.5mm-3.5mm audio cable




User manual

### **Note:**

- Images are for illustrative purposes only and may differ from the actual product.
- For the need of technical improvement and system upgrade, information and specifications contained herein may be slightly different from actual product. If any difference is found, the actual product prevails.

## Functional operation



### 1. Earphone port

### 2. Power switch/ volume control

Power ON: rotate the knob to the right, it's ON if there is a "click" prompt tone

Power OFF: rotate the knob to the left, it's OFF if there is a "click" prompt tone

Volume up: rotate the knob clockwise

Volume down: rotate the knob counterclockwise

### 3. Mode indicator

USB input: red LED steady lit

Bluetooth input: blue LED steady lit

AUX input: green LED steady lit

### 4. Mode switch button

Press: USB-Bluetooth-AUX mode switch

Press and hold: disconnect Bluetooth and clear pairing information (Bluetooth connected state)


### 5. AUX input

### 6. USB connecting port /Active & passive speaker connecting port

### 7. Connect to active speaker


## ■ Operation instructions

### ● USB connection




Connect the USB cable to the computer, then rotate the “power switch/ volume control” knob to the right to power on. You can enjoy it after the computer automatically installs the USB driver.

### ● AUX connection



After the speaker is on, connect the 3.5mm-3.5mm audio cable to your device and the speaker. The green LED will be steady lit when automatically switch to AUX mode. Select the audio file on your device to play.

- **Bluetooth connection**



Press the “mode switch button” to switch to Bluetooth input. Blue LED will blink slowly. When the speaker automatically enters the Bluetooth pending state, select "EDIFIER R19BT" in your device setting to connect. Blue LED will be steady lit after the connection is successful.

- **Specifications**

Power output: R/L: 2W+2W

Frequency response: 78Hz-19KHz

Noise level:  $\leq 25\text{dB(A)}$

Input: 5V=1A

- Model NO.:EDF100039

## **Troubleshooting**

### **No sound**

- Check if the speaker is ON.
- Try to turn up the volume using either the master volume control or remote control.
- Ensure the audio cables are firmly connected and the input is set correctly on the speakers.
- Check if there is a signal output from the audio source.

### **Cannot connect via Bluetooth**

- Make sure the speaker is switched to Bluetooth input. If it is in other audio input modes, Bluetooth will not connect. Disconnect from any Bluetooth device by pressing and holding the mode switch button in Bluetooth mode, then try again.
- Effective Bluetooth transmission range is 10 meters; please ensure that operation is within the range.
- Try another Bluetooth device for connection.

### **Noise coming from speakers**

- EDIFIER speakers generate little noise, while the background noise of some audio devices are too high. Please unplug audio cables and turn the volume up, if no sound can be heard at 1 meter away from the speaker, then there is no problem with this product.