





● **LMH4**


2140 MHz






2350 MHz











2450 MHz























2600 MHz















● **LMH4**













● **MH2**



1440 MHz





1740 MHz



1880 MHz




1950 MHz






● **MH2**


2140 MHz






2350 MHz



2450 MHz




2600 MHz








● **MH2**


3600 MHz








4000 MHz



4700 MHz




5500 MHz






● **MH3**


1440 MHz






1740 MHz



1880 MHz





1950 MHz






● **MH3**



2140 MHz




2350 MHz





— 2110MHz
— 2140MHz
— 2170MHz






— 2300MHz
— 2350MHz
— 2400MHz





2450 MHz




2600 MHz



— 2410MHz
— 2450MHz
— 2480MHz




— 2500MHz
— 2600MHz
— 2700MHz






● **MH3**


3600 MHz






4000 MHz



4700 MHz




5500 MHz






● **MH4**


1440 MHz






1740 MHz



1880 MHz




1950 MHz






● **MH4**


2140 MHz



2350 MHz



2450 MHz



2600 MHz

