

## User Manual

### Introduction

By using Bluetooth headset, you can make a call even when you are travelling outside or having in the office. You can connect the headset to your mobile phone which supports the Bluetooth technology. Before you use the product, you are suggested to read this manual carefully for better understanding about the product functions, our service support and warranty information.

### Product description

Product: Mono Bluetooth

Charge: AC adapter DC 5V 150MA    USB cable +5V

Bluetooth Version: Class 2.1

Support agreement: HFP 1.5, HSP1.0

The Bluetooth headset is fit for the 2.1 Bluetooth and the EDR standards. And it also supports the 1.1 and 1.5 hands free modes. Please consult the producer to make sure if this headset is compatible to your devices.

### Pairing the headset

1. Please make sure to put the two items within 1 M
2. Make sure that the headset is power off, and push the button for a while until the red indicator is flashed alternated with the blue indicator; the headset is in the

situation of pairing.

3. Open the “Bluetooth searching” or “add new device” to select the headset from the list.
4. Input the code “0000” to build the connection. Details on your mobile phone user manual. You don’t have to rebuild the connection the next time you use. Some cell phones can connect automatically without code.

When the pairing is completed, the headset will be on the function list of Bluetooth devices, you can check the equipment on the list.

### Charging the battery

The build-in battery of the headset can not be disassembled.

Please do not attempt to take the battery out, it may cause damage to the headset.

For the first time you use headphones, please charge for the headsets for 5 hours to achieve optimal battery capacity and life time.

1 Connect the charge cable or USB cable to the headset. During charging, the red light will be on, when it goes out, the charging is completed. Normally, the charging time is about 3 hours.

### 2 Low-power Alarm

When the power goes low, the headset will buzz with interval, and please charge for the headset.

### Warm tips

- Before using the headset, please check out if the charger is fit for the headset.
- Do not use any other types of charger, because it may cause broken.
- When the charger is not using, please disconnect the link and remove the charger from the power supply. Over charging could shorten the life time

of the battery. Without using for a long period, the battery could discharge itself.

- Extremely cold or hot environment could shorten the capacity and the life time. Please keep the headset ideally in the condition of 15°C to 25°C. When the temperature is under 0°C, the performance of battery would be affected.
- Do not put the headset into water or fire.

### Turn headset on

When the headset is power off, press and hold the functional button for a while and then the blue indicator will light.

### Turn headset off

When the headset is power on, press and hold the functional button for a while and then the indicator will off.

### Answer Phone

When the call comes in, the headset and phone will beep or ring, push the functional key to answer the phone.

### End the Call

During the call, push the functional key to hang up or you can wait for the disconnecting performed by your party.

### Redialing for the Last Call

Under the standby condition, quickly push the functional key twice to redial the last call.

### Refuse the Call

When the call comes in, push the functional key for 2 seconds to refuse the call.

### Voice dial

When you push the functional button once, the mobile phone remains you that you can start the voice dialing, say the name saved in your contacts, it will dial automatically.

Ps. Make sure that your mobile phone support the voice

dialing function.

#### Volume adjustment

During call, shortly push volume (+) to increase the volume

During call, shortly push volume (-) to decrease the volume

Note: If Bluetooth headset don't have the volume button, please adjust your mobile phone the volume.

**Warm tips:** To protect your hearing, please set the volume on the safety level.

All the functions above are only fit to Bluetooth headset which supports the Bluetooth hands free function. Different brands or different menus may cause different using methods. Please check your manual of your mobile phone.

#### FAQ:

1. What is the working distance of the Bluetooth headset?

**Answer:** 30 inches (or 10 meters)

2. Is the Bluetooth headset fit for cordless telephone?

**Answer:** the Bluetooth headset is not fit for cordless telephone.

3. Is the Bluetooth headset fit for PC or PDA?

**Answer:** It only fit for devices which support the Bluetooth function and Bluetooth standard above.

4. Will the Bluetooth headset be disturbed?

**Answer:** Cordless telephone or wireless internet device may cause disturbs with some sound. Put the earphone away from these devices to avoid disturb.

5. Will the Bluetooth headset cause interference to the car devices, broadcast or computers?

**Answer:** The power of Bluetooth headset is lower than normal mobile phone, and it only can send the global standard signs.

6. Will the other Bluetooth users hear my call?

**Answer:** It's the private connection between your headset and device. It can not be monitored by third party. The sign it send is much lower than normal mobile phones.

7. How to maintain the Bluetooth headset?

**Answer:** Clean the earphone by little humid clean soft cloth.

8. Why the Bluetooth headset disconnect during using occasionally?

**Answer:** Out of efficient distance or low voltage may cause the earphone out of connection.

#### Elimination of break

If you can't connect the earphone and the device, please perform the steps following:

- Make sure the headset has been charged; the earphone is power on and paired with the device.
- Make sure the Bluetooth function of device has started up.
- Make sure the distance between earphone and device is within 10 meters and there are no barriers between them.

If all these steps can not solve your problem, please charge it and take out the battery of your cell phone.

#### Product Maintains

- Switch off the earphone before you put it into pocket, it may dial if you push the functional key by accident.

- Do not put the earphone in liquid, humid or damp environment.
- Do not clean the earphone by abrasive cleansers.
- Do not put the earphone in over-cold or over-hot conditions.
- The earphone may explode if deposed of in fire.
- Do not contact to sharp items, it may cause scratch.
- Do not insert anything to the headset, it may cause internal broken.
- Do not disassemble by yourself.
- Put it in dry invariable temperature condition if you plan not use it for a long time.
- Do not change the build-in battery, it can't be changed.
- Follow the instruction or the guide book to charge for the battery.
- During charging, use specified charger only.
- When the headset is not used in a long period, please charge for it at least once three months.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes and modifications to this equipment. Such changes and modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.