










成品尺寸: 68x 68 mm ±0.2 mm 印刷尺寸: 680x 68 mm

80P 金東太空梭紙/雙面印刷 彈簧摺: 9摺

Pantone 151C

Before you start	Brinno App	1-1. Connect to Android Phone	1-2. Connect to iPhone	1-3. Re-connect to The Smartphone	2. Record A Time Lapse Video In The App	3. Time Lapse Video Playback
<p>Please make sure to follow these steps before you start:</p> <ol style="list-style-type: none"> 1. Download the Brinno App 2. Fully charge the battery 3. Insert a Micro SD Card 	<p>1. Camera: connect to a smartphone 2. Editing: video editing 3. Gallery: video playback 4. App settings 4-1. Video 4-2. Language settings</p> 	<p>1. Turn on the camera (hold the "Power button" for 3 seconds or until the greenlight is on). 2. Turn on Bluetooth and Wi-Fi on your phone. 3. Open the Brinno App. 4. Press the "Camera Button". 5. List of cameras, select the camera (SSID) TLC130-XXXXXX. 6. Press "Connect". 7. Complete Bluetooth connection, "Connect Wi-Fi?" pops up, press "OK". 8. Shows Wi-Fi connection settings, "AP Mode" is set to default. 9. In the meantime, camera will automatically connect to your phone. 10. "Successfully Connected" pops up, press "OK". 11. Now you see the preview screen in the app.</p> 	<p>1. Turn on the camera (hold the "Power button" for 3 seconds or until the greenlight is on). 2. Turn on Bluetooth and Wi-Fi on your phone. 3. Open the Brinno App. 4. Press the "Camera Button". 5. List of cameras, select the camera (SSID) TLC130-XXXXXX. 6. Press "Connect". 7. Complete Bluetooth connection, "Connect to Wi-Fi?" pops up, press "Connect". 8. Then, pops up will illustrate "how to connect the Wi-Fi". 9. Go to Settings -> Wi-Fi -> select: TLC130-XXXXXX -> Password: 12345678. 10. Once you finished, go back to Brinno App. 11. "Successfully Connected" pops up, press "OK". 12. Now you see the preview screen in the app.</p> 	<p>If the "Connect to Wi-Fi" does not show up automatically after recording, Please connect to the smartphone again.</p> <ol style="list-style-type: none"> 1. Press "Settings" icon. 2. Select "Wi-Fi Connection". 3. Select a filter. 4. Press "<" to go back. <p>Camera offers 3 different functions: Photo, Time Lapse, Video. Video mode allows you to record video up to a minute and share.</p>	<p>1. When camera is successfully connected to a smartphone. 2. Press the scene filter icon. 3. Select a filter. 4. Press the record button again to stop recording.</p> 	<p>1. When camera is successfully connected to a smartphone. 2. Select the file icon. 3. Select a video in the folder. 4. Press the play button. 5. Press "<" to return to the folder. 6. REC During recording status, the camera connection cannot be change. 7. Press the play button. For power saving purpose, camera will turn off the Wi-Fi connection during time lapse video recording. To re-enable camera preview, you must reconnect to the camera's Wi-Fi after you done recording.</p> 

封底

4. Save Time Lapse Videos Into Smartphone	5. Time Lapse Video Editing	FCC	WIFI Full HD Time Lapse Camera	
<p>1. When camera is successfully connected to a smartphone. 2. Select the "File" icon. 3. Press "Select Button" on the upper right. 4. Select videos in the folder. (i) 5. Press "Transfer".</p> <p>It is possible to transfer multiple videos at the same time, but the transmission process might be longer.</p> 	<p>6. For iPhone users, please "Allow" camera to access to your phone's gallery. 7. Do not leave or turn off the App when transferring files. 8. After the videos are successfully transferred, you can watch them on your phone's gallery.</p> 	<p>After the videos are successfully transferred, you can start editing.</p> <p>Editing functions:</p> <ol style="list-style-type: none"> 1. Go back to the App. 2. Select Editing. 3. Press "Select" in "My Media" folder. 4. Select a video that you wish to edit. (One video at a time) 5. Select "+" to start editing. 	<p>Cutting:</p> <ol style="list-style-type: none"> 1. Drag the two time bars to where you want to cut the video. 2. Select "confirm". <p>Music:</p> <ol style="list-style-type: none"> 1. Press "Background Music". 2. Music: Import music from your phone. 3. My music: Free music is included. <p>Share:</p> <p>Once you've done editing, you can choose to save the video into your phone, or share it on any social media platform.</p> 	<p>FCC FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna. --Increase the separation between the equipment and receiver. --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help.</p> <p>BSMI 有賣池產品 CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS</p> <p>警告 本電池如果更換不正確會有爆炸的危險。請依製造商說明書處理過期電池。</p> <p>NCC P002 低功率電波輻射性電機管理辦法 第十二條 經型式認證合格之低功率射頻電機，非經許可、公司、商號或使用者均不得擅自變更頻率、加大功率或變更設計之特性及功能。 第十四條 低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停止使用並改善後方可繼續使用。前項之改善辦法，由指揮官依各項無線電通信、低功率射頻電機之管製辦法定之。</p> <p>WIFI Full HD Time Lapse Camera</p> <p>TLC130 User Manual</p> <p>brinno</p>