




Le Bébé  
PLEASURE AWAITS

English  
Français  
Italiano  
Deutsch  
Dutch  
Español  
Русский  
繁體中文

EXTASE

## Congratulations on acquiring the Le Bébé pleasure object.



### CHARGING

Before charging, make sure the DC Socket is free from water or lubricant residue.

1. Gently remove the protective Silicone Cap on the side of your Le Bébé Egg or Remote.
2. Slowly insert the DC plug into the DC Socket, until you feel a subtle "click".
3. Insert the main plug into the wall socket. The LED will pulsate to indicate that the Egg or Remote is charging. When they are fully charged, the LED will remain on.


Do not use your Le Bébé while charging.  
Do not charge for more than 24 hours.  
Only use original chargers provided by EXTASE.

If the battery is running low, the LED Indicator will signal you to charge by emitting a white sheen, the device will continue to function for one minute. When the white sheen ceased, the device will discontinue its operation and the LED indicator will signal in white when either part of the dial is pressed.

### USING YOUR Le Bébé

ON / OFF, vibration intensity and stimulation patterns are all controlled with the Interface Dial on the Remote. When either part of the dial is pressed, the LED will indicate that the interface is active.

1. Press the  $\oplus$  Activation Dial on the Egg distinctly for one second to enter stand-by mode.
2. Press the  $\oplus$  Interface Dial on the Remote to activate your



Le Bébé. Keep pressing the  $\oplus$  Interface Dial until you reach the vibration intensity you desire.

3. To decrease vibration intensity, press the  $\ominus$  Interface Dial.
4. To switch between stimulation patterns, press the  $\ominus$  Interface Dial.
5. To turn OFF the vibration, keep pressing the  $\ominus$  Interface Dial until vibration cease.
6. To turn OFF anytime or exit stand-by mode, press the  $\ominus$  Activation Dial on the Egg distinctly for two seconds.

### SYNCHRONIZING YOUR Le Bébé

Your Le Bébé is synchronized at default; however please re-synchronize your Le Bébé when your battery runs out or if you wish to synchronize your Remote with more than one Egg(s).

1. Press the  $\ominus$  Activation dial of the Egg for five seconds to enter synchronization mode, the LED will pulsate quickly for ten seconds.
2. At any time during the ten second interval, press any Interface Dial button on the Remote, this will automatically synchronize the Remote and the Egg(s), the LED will pulsate slowly three times to indicate that synchronization is successful.

To synchronize with another Egg(s), repeat steps 1 to 2.

### CLEANING

- Never use massage oil and hand cream as lubricants or cleansers containing alcohol, petrol or acetone.
- Always clean Le Bébé thoroughly before and after each use. Wash with warm water, toy cleaner, antibacterial soap, rinse and pat dry.

### WARNING

- Do not use the Le Bébé on swollen, inflamed or wounded area.
- Stop using it if you feel pain or discomfort.
- It is not recommended for pregnant women to use Le Bébé.
- Do not use this product underwater.

### TROUBLESHOOTING

Q: LED does not pulsate while charger is connected.  
A: Battery is drained and will require several minutes to acknowledge charger.  
A: Charger is not properly connected. Check wall and DC Socket.  
Q: Le Bébé does not activate when the  $\oplus$  Interface Dial is pushed.  
A: Battery is empty. Recharge your Le Bébé.

A: Switch your Egg to the "Stand-by" mode by pressing on the  $\ominus$  Activation Dial.

A: Synchronize your Egg with the Remote. Follow instructions in "SYNCHRONIZING YOUR Le Bébé".

Q: Le Bébé cannot be switched OFF and / or Interface Dial does not respond

A: Connect the charger to restore interface functionality.

If you experience any other problems with your Le Bébé or if you have any questions regarding its operation, please contact : service@myextase.com

### SPECIFICATIONS

MODEL NUMBER	C1
COLOURS	Pink / Blue
MATERIALS	PC / ABS / Silicone
FINISHES	Matt / PU Coating
SIZE	EGG 64 x 32 x 25 mm 2.53 x 1.28 x 1.00 inch REMOTE 68 x 30 x 24 mm 2.67 x 1.20 x 0.96 inch
WEIGHT	EGG 28.8 grams REMOTE 23.2 grams
BATTERY	EGG 1 x 120 mA Li-Ion Battery (3.7V) REMOTE 1 x 120 mA Li-Ion Battery (3.7V)
CHARGING	1.5 hr at 5 V 1A
USER TIME	Up to 2.5 hours
STAND-BY	Up to 60 days
FREQUENCY	80 Hz
INTERFACE	EGG Single Dial $\ominus$ REMOTE Interface Dial $\oplus$ $\ominus$ $\ominus$ $\oplus$

### APPLICABLE ACCESSORIES : DC-USB POWER Y CABLE / ADAPTER

Transmitter FCC ID: ZF5C1001  
Receiver FCC ID: ZF5C1002  
MADE IN CHINA

### FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

The instructions for appliances having a part of class III construction supplied from a detachable power supply unit shall state that the appliance is only to be used with the power supply unit provided with the appliance.

The instructions for class III appliances shall state that it must only be supplied at safety extra low voltage corresponding to the marking on the appliance. This instruction is not necessary for battery-operated appliances if the battery is a primary battery or secondary battery charged outside of the appliance.

### MAINTENANCE

- The lifespan of your Le Bébé will greatly increase with proper maintenance and care.
- Avoid submerging and getting water into the DC Socket or around the Interface dial.
- Store your Le Bébé in the satin pouch provided and keep it away from toys of other materials.
- Avoid leaving your Le Bébé in direct sunlight and NEVER expose it to extreme heat.

### DISPOSAL INFORMATION

Disposal of old electronic equipment is applicable in the EU and other European countries that separate waste collection systems. We urge users outside of Europe to also follow local waste treatment regulations.

The crossed-out dustbin symbol indicates that this pleasure object should not be treated as household waste, but be handed over to the applicable collection point recycling as electrical equipment. You will help prevent potential negative consequences for environment and human health by disposing this product correctly. The recycling of materials will further help conserve natural resources.

### WARRANTY

In line with the European regulations, our products are guaranteed within the limits planned by the law.

### DISCLAIMER

User of this pleasure object uses the pleasure object at his / her own risk. Neither EXTASE nor wholesalers / retailers assume any responsibility or liability for the use of this pleasure object. Model may be changed for improvements without notice.

### DECLARATION OF CONFORMITY

FUFI LIFESTYLE CO., LTD.  
Unit 706, Haleson Building, No. 1 Jubilee Street, Hong Kong  
Declares under our sole responsibility that the product:  
Name of product: Le Bébé  
Type of product: Sensual Egg

The product specified above complies with the requirements of the following directives and carries the CE mark accordingly:



URL: [www.myextase.com](http://www.myextase.com)

SUPPORT: [service@myextase.com](mailto:service@myextase.com)