



User Guide & Important Information
Bluetooth Speaker Model:BSK26



Located in Southern California, White Label designs high performance products more efficiently, resulting in high quality products that are reasonably priced. We don't offer fancy packaging, phony marketing stunts, or expensive celebrity endorsements - what we do offer is much more bang for your buck.

CONTENTS

	Page
Welcome to the wireless waterproof Bluetooth speakers...	3
Product Description.....	4
What's Inside	5
Button Controls.....	6
Charge the Speaker.....	7
Connecting with Bluetooth.....	8
Getting Started Guide.....	9
Basic operation.....	11
Making voice calls.....	15
Battery low-voltage alert.....	16
About battery.....	18
Fcc Caution.....	21
Contact Us.....	25

WELCOME TO THE WIRELESS WATERPROOF BLUETOOTH SPEAKER

Thank you for buying the SoundDew Waterproof Bluetooth Speaker. This speaker is designed to be convenient, stylish and provide high quality audio Playback from any Bluetooth enabled Audio Device or wired only device.

The SoundDew Waterproof Bluetooth Speaker can also be used to receive telephone calls while in use and will automatically pause the audio playback in order to receive the call and when the call ends audio Playback will resume.

Please read this user Guide thoroughly before use so that you can understand the setup and functions.


PRODUCT DESCRIPTION

SoundDew Waterproof Bluetooth Speaker design combines fashion elements and new wireless technology. Its compact and stylish design fully meet the needs of an active lifestyle. It is waterproof and dustproof, mainly suitable for outdoor sports, family bathroom use.


The purpose of this manual is to help you use your new SoundDew series Bluetooth speaker correctly.

This manual also provides additional features about this product and related important information.

WHAT'S INSIDE



WhiteLabel
SoundDew Waterproof
Bluetooth Speaker




Line-IN Audio Cable



USB to Micro -USB
Charging Cable

BUTTON CONTROLS



1.VOL+

2.Multifunction Key


3.VOL-

4.USB interface

5.Line in interface

6.MIC

CHARGE THE SPEAKER



Note:

Please fully charge the battery before 1st time use. This can be performed using the Provided USB Cable and any powered USB Port.

1ST TIME CONNECTION WITH BLUETOOTH

1. The first time you switch on the Speaker the LED light will flash Red and Blue and you'll hear an audio tone The Speaker is automatically looking to connect to a Bluetooth device.
2. Go to the Bluetooth option in the settings of your Bluetooth Audio device or Smartphone and in the list of devices select Soundew.
3. The speaker is now ready to use.

GETTING STARTED GUIDE

Turn On

Turn ON: Press the MFB button for 3 seconds, the blue light will flash 3 times.

Two kinds of connections

1. Bluetooth wireless connection
2. 3.5mm audio cable connection

Connection indication

3.5mm audio cable connection

Plug one end of the 3.5mm audio cable into speaker audio AUX port on the speaker and the other end into the device you want to connect.(such as mobile, MP3, ipad, etc.)

GETTING STARTED GUIDE

LED indication status

Standby:	Blue light flash 1 times every 7 seconds
No connection:	Blue light flash 2 times every 5 seconds
Incoming call:	Blue light flash 2 times every 2 seconds
During a call:	Blue light flash 1 times every 7 seconds
Charge:	Red light remains on.
Charge finish:	Red light off

BASIC OPERATION

1. Turn on: In the off state, press the MFB button for 4 seconds, the blue LED flashes three times with an indication tone.
2. Turn off: In the on state, press the MFB button for 3 seconds, the red LED flashes three times with an indication tone.
3. Pairing: 1st time you switch on the speaker it will automatically look for a device to connect with. Note: If already paired with a Bluetooth device it will automatically connect.
4. Connection: Connect your phone to the Bluetooth speaker after pairing is successful.

BASIC OPERATION

5. Answer a call: After connection is successful, short press the MFB button to answer an incoming call.you will hear an indication tone.
6. End a call: When the call is connected successfully , short press the MFB button to hang up , with an indication tone.
7. Reject a call: Hold the MFB button for 3 seconds to reject an incoming call , you will hear an indication tone.
8. Voice transfer: During a call , hold the MFB button for 3 seconds until hear an tone, then the voice begin to be transferred from the Bluetooth speaker to your phone , the same operation can transfer the sound from your phone to a Bluetooth speaker.

BASIC OPERATION

9. Microphone mute: Long press the “VOL-“ button for 3 seconds can switch to open and close the mute function, the red and blue light will flash once together, you will hear an indication tone every 5 minutes.
10. last number redial: In the standby mode , press the “+” button for 3 seconds will redial the last outgoing number.you will hear an indication tone.
11. Voice dial: In the standby mode, Double click the MFB button to start voice dial,you will hear an indication tone.
(Need the support of the mobile phone Bluetooth)

BASIC OPERATION

12. Adjust the volume: when answering, dialing or during a call, short press "+" button to increase volume, and you will hear an indication tone when increase to maximum volume. Similarly, short press "-" button to decrease the volume, and also an indication tone when decrease to minimum volume.
13. Pause/play/next/previous: These functions need to control from your mobile phone.
14. To connect with a different Bluetooth device, 1st switch off the Bluetooth device, next switch off the speaker. When you turn on the Speaker again you'll be able to connect to another device.

MAKING VOICE CALLS

It is possible to make a call directly from the speaker using voice recognition. To use this voice dialing function, your Phone must provide this option.

1. Enable voice recognition function of your Phone and set the Phone to hands free mode.
2. Double press the Multifunction Button of the speaker, you will hear a tone.
3. Say the name of the person you wish to call loudly.
(Remarks: Speaker's voice call function is determined by the cell phone)

BATTERY LOW-VOLTAGE ALERT

Red light will remain on during charging, will turn off when charging is finished. It will take 2-3 hours to finish charging. Please charge the battery in time. When red light flashes and alert tone sounds once every 1 minute.

NOTES

NOTE

1. Pairing mode will last 5 minutes. other mobile phone cannot search out the bluetooth speaker.
2. Re-connecting automatically (includes two cases)
 - A. If the bluetooth speaker turned off, it will connected to the pre-set bluetooth speaker automatically When turn on manually.
 - B. When the SoundDew disconnects to mobile phone owing to exceeding effective range (normally Link loss if exceed 10M), the bluetooth speaker will re-connect to mobile phone if back to effective range within about 10 minutes.
3. When no connection, bluetooth speaker will automatically shut down after 10 minutes.

ABOUT BATTERY

The Bluetooth speaker is powered by a rechargeable battery , new battery achieve the best performance only after two or three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times , but it will eventually wear. When not charging , disconnect it with Bluetooth speaker. Do not leave a fully charged battery connected to a charging circuit since overcharging may shorten battery life. If a fully charged battery is left unused, the battery itself will be discharged after a period of time. If place the battery in hot or cold places , such as a closed car in summer or winter , will reduce the battery capacity and lifetime. Battery temperature should be maintained at between 15-25 centigrade. Bluetooth speaker battery too

ABOUT BATTERY

hot or cold may make it not work temporarily , even if the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing . Do not dispose of batteries in a fire in order to avoid battery explosion. Impaired batteries may also explode.

- Avoid placing this product near extreme temperatures or humidity.
- Do not use this product while operating a motor vehicle.
- Do not submerge or allow this product to come into contact with water. Use in dry locations only.
- An adult should supervise young children when using this product.

ABOUT BATTERY

- Use of any attachment or accessory with this product not recommended or sold by White Label may result in risk of fire, electrical shock or injury to persons or product.
- Do not clean any parts with alcohol, cleaning solutions containing alcohol or strong abrasives. Use a soft cloth and a little water.
- There are no user serviceable parts within this product. Tampering with this product will invalidate your warranty.

FCC warning statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

CONTACT US

Irvine Mobility, Inc.
www.whitelabel.co
support@whitelabel.co



©IRVINE MOBILITY 2013. The product and packaging are trademarks or registered trademarks of IRVINE MOBILITY, INC. in the United States or other countries. All rights reserved. The Bluetooth® word mark and logos are owned by Bluetooth® SIG, Inc. and any use of such marks is under license. Other trademarks and trade names are registered mark of their respective owners.