


# Users Manual

## 1 Sketch map



## 2. Speaker Operation

function	status before operate	operation	indicator light on speaker
switch on	switch off status	long time press power key for 3s	red light light
switch off	switch on status	long time press power key for 3s	indicator light off
play/pause	connecting status	short time press MULT key	Blue light long time
VOL+	play status	Long time press VOL+/VOL-	Blue light long time
VOL-	play status	short time press VOL+/VOL-	Blue light long time
connection	no connect status	short time press Mult key	Blue LED light long time
Light	Switch on status	short time press light key	Two side light will be lighted

Low battery warning: when 6pcs 3A battery's total voltage are 7.2V (average every pcs lower than 1.2V), the red light will flash every 20s, meantime will hear a sound “dudu”. Means need to change the battery.

Play/Pause: Press MULT key just speaker mute, the music won't stop to

play.

If switch on the speaker at first, then switch on the adapter and 3.5mm cable connect with adapter, the adapter and speaker will connect automatic.

If the adapter switch off then switch on, it could connect speaker automatic, however, if speaker switch off then switch on, it need to press MULT key or speaker key to connect.

## **FCC WARNING**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.